



MX Magnum - Service Manual Complete Table of Contents

Description	Book Number	Section Number	Publication Number
Standard Torque Specifications	1	1000	6-14200
Safety, General Information/Maintenance Schedule	1	1001	6-14200
General Specifications and Special Torques	1	1002	6-14200
Engine Removal and Installation	1	2002	6-14200
Fuel Tank Removal and Installation	1	3001	6-14200
Electrical System (Prior to P.I.N. JAZ129933) How it Works and Troubleshooting	2	4001	6-14210
Electrical System (P.I.N. JAZ129933 and After) How it Works and Troubleshooting	2A	4001	6-12741
Steering Column and Steering Hand Pump	3	5001	6-14221
Powershift Transmission System How it Works and Troubleshooting	3	6000	6-14221
Transmission Input Shaft and Drive Plate	3	6001	6-14221
Input Drop Box	3	6002	6-14221
Engine Frame and Input Drop Box Split	3	6003	6-14221
Speed to Range Transmission Split	3	6005	6-14221
Speed Transmission	3	6006	6-14221
Range Transmission to Rear Frame Split	3	6007	6-14221
Range Transmission	3	6008	6-14221
Transmission Control Valves and Inching Valve	3	6009	6-14221
Rear Frame	4	6011	6-14231
Hydraulic Pump Drive	4	6012	6-14231
Mechanical Front Drive MFD Control System How it Works	4	6013	6-14231
Differential Lock Control System How it Works	4	6014	6-14231
MFD Clutch And Output Shaft Removal Without Tractor Split	4	6015	6-14231
MFD Drive Shaft	4	6016	6-14231
Limited Slip MFD Differential	4	6017	6-14231

Description	Book Number	Section Number	Publication Number
Locking MFD Differential	4	6018	6-14231
Rear Axle and Planetaries	4	6019	6-14231
Power Take Off Control System How it Works	4	6020	6-14231
MFD Planetary Hub, Steering Knuckle, and Axle Drive Shaft	4	6022	6-14231
Suspension MFD Axle	4	6023	6-14231
Suspended MFD Axle System How It Works and Troubleshooting	4	6024	6-14231
Brake Valve	4	7001	6-14231
Brake Cylinders	4	7002	6-14231
Park Brake	4	7004	6-14231
Trailer Brake System - How It Works	4	7005	6-14231
PTO Assembly - Single and Dual Speeds	4A	6021	7-86731
PTO Clutch Assembly Single and Reversible Single Speeds	4A	6025	6-17540
How to Read Symbols in a Hydraulic Schematic	5	8000	6-14241
Hydraulic System How it Works with Troubleshooting	5	8001	6-14241
PTO and Differential Lock Valve	5	8002	6-14241
Remote Valve and Coupler Service	5	8003	6-14241
Remote Hydraulic System How it Works and Troubleshooting	5	8004	6-14241
Priority and Regulator Valve	5	8005	6-14241
Charge Pump	5	8006	6-14241
PFC Piston Pump and Hydraulic Filter	5	8007	6-14241
Hitch System - How it Works	5	8008	6-14241
Hitch Control Valve	5	8009	6-14241
Pedal & Pedal Switch Adjustments	5	9001	6-14241
Cab Raise/Removal and Installation	5	9005	6-14241
Tilt And Fixed Hoods, A/C Condenser, Radiator, And Air-To-Air Aftercooler	5	9008	6-14241



Description	Book Number	Section Number	Publication Number
Air Conditioning Troubleshooting	5	9010	6-14241
Air Conditioner System Service	5	9020	6-14241
Viscous Fan Drive Test	5	9030	6-14241
Standard Instrumentation Programming and Fault Codes	6	10001	6-14250
Hitch Controller Calibration and Fault Codes	6	10002	6-14250
Transmission Controller (With Suspended Axle) Calibration and Fault Codes	6	10003	6-14250
Armrest Controller Calibration and Fault Codes	7	10004	6-14260
Remote Hydraulics Controller Calibration and Fault Codes	7	10005	6-14260
PTO Controller Configuration and Fault Codes	7	10006	6-14260
Performance Monitor Controller Fault Codes	7	10008	6-14260
Instrument Cluster (ICU2) Programming and Fault Codes	8	10009	6-17550



Service Information Packaged with 6-12722

Electrical Schematic (Prior to P.I.N. JAZ129933) 6-12750

Electrical Schematic (P.I.N. JAZ129933 and After) 6-17260

Hydraulic Schematic 6-12830

Loctite Product Chart 8-98902

A/C Temperature Poster 6-13060

Service Information Not Packaged with 6-12723 But Required for Engine Repair

Electronic 8.3L Engine for MX255 and MX285 Manual Numbers 7-88622 and 7-88631

Mechanical 8.3L Engine for MX210 and MX230 Manual Number 7-65440









Section 1000

Standard Torque Specification

TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphites, Molydisulfide greases, or other extreme pressure lubricants are used.


Grade 5 Bolts, Nuts, and Studs		
  		
Size	Pound-Inches	Newton metres
1/4 inch	108 to 132	12 to 15
5/16 inch	204 to 252	23 to 28
3/8 inch	420 to 504	48 to 57
Size	Pound-Feet	Newton metres
7/16 inch	54 to 64	73 to 87
1/2 inch	80 to 96	109 to 130
9/16 inch	110 to 132	149 to 179
5/8 inch	150 to 180	203 to 244
3/4 inch	270 to 324	366 to 439
7/8 inch	400 to 480	542 to 651
1.0 inch	580 to 696	787 to 944
1-1/8 inch	800 to 880	1085 to 1193
1-1/4 inch	1120 to 1240	1519 to 1681
1-3/8 inch	1460 to 1680	1980 to 2278
1-1/2 inch	1940 to 2200	2631 to 2983


Grade 8 Bolts, Nuts, and Studs		
  		
Size	Pound-Inches	Newton metres
1/4 inch	144 to 180	16 to 20
5/16 inch	288 to 348	33 to 39
3/8 inch	540 to 648	61 to 73
Size	Pound-Feet	Newton metres
7/16 inch	70 to 84	95 to 114
1/2 inch	110 to 132	149 to 179
9/16 inch	160 to 192	217 to 260
5/8 inch	220 to 264	298 to 358
3/4 inch	380 to 456	515 to 618
7/8 inch	600 to 720	814 to 976
1.0 inch	900 to 1080	1220 to 1465
1-1/8 inch	1280 to 1440	1736 to 1953
1-1/4 inch	1820 to 2000	2468 to 2712
1-3/8 inch	2380 to 2720	3227 to 3688
1-1/2 inch	3160 to 3560	4285 to 4827
NOTE: Use thick nuts with Grade 8 bolts.		

TORQUE SPECIFICATIONS - METRIC HARDWARE

Use the following torques when specifications are not given.

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or Molydisulfide grease or oil is used.

Grade 8.8 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
M4	24 to 36	3 to 4
M5	60 to 72	7 to 8
M6	96 to 108	11 to 12
M8	228 to 276	26 to 31
M10	456 to 540	52 to 61
Size	Pound-Feet	Newton metres
M12	66 to 79	90 to 107
M14	106 to 127	144 to 172
M16	160 to 200	217 to 271
M20	320 to 380	434 to 515
M24	500 to 600	675 to 815
M30	920 to 1100	1250 to 1500
M36	1600 to 1950	2175 to 2600

Grade 10.9 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
M4	36 to 48	4 to 5
M5	84 to 96	9 to 11
M6	132 to 156	15 to 18
M8	324 to 384	37 to 43
Size	Pound-Feet	Newton metres
M10	54 to 64	73 to 87
M12	93 to 112	125 to 150
M14	149 to 179	200 to 245
M16	230 to 280	310 to 380
M20	450 to 540	610 to 730
M24	780 to 940	1050 to 1275
M30	1470 to 1770	2000 to 2400
M36	2580 to 3090	3500 to 4200

Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
37 Degree Flare Fitting			
1/4 inch 6.4 mm	7/16-20	72 to 144	8 to 16
5/16 inch 7.9 mm	1/2-20	96 to 192	11 to 22
3/8 inch 9.5 mm	9/16-18	120 to 300	14 to 34
1/2 inch 12.7 mm	3/4-16	180 to 504	20 to 57
5/8 inch 15.9 mm	7/8-14	300 to 696	34 to 79
Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
3/4 inch 19.0 mm	1-1/16-12	40 to 80	54 to 108
7/8 inch 22.2 mm	1-3/16-12	60 to 100	81 to 135
1.0 inch 25.4 mm	1-5/16-12	75 to 117	102 to 158
1-1/4 inch 31.8 mm	1-5/8-12	125 to 165	169 to 223
1-1/2 inch 38.1 mm	1-7/8-12	210 to 250	285 to 338

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
Straight Threads with O-ring			
1/4 inch 6.4 mm	7/16-20	144 to 228	16 to 26
5/16 inch 7.9 mm	1/2-20	192 to 300	22 to 34
3/8 inch 9.5 mm	9/16-18	300 to 480	34 to 54
1/2 inch 12.7 mm	3/4-16	540 to 804	57 to 91
Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
5/8 inch 15.9 mm	7/8-14	58 to 92	79 to 124
3/4 inch 19.0 mm	1-1/16-12	80 to 128	108 to 174
7/8 inch 22.2 mm	1-3/16-12	100 to 160	136 to 216
1.0 inch 25.4 mm	1-5/16-12	117 to 187	159 to 253
1-1/4 inch 31.8 mm	1-5/8-12	165 to 264	224 to 357
1-1/2 inch 38.1 mm	1-7/8-12	250 to 400	339 to 542

Split Flange Mounting Bolts		
Size	Pound- Inches	Newton metres
5/16-18	180 to 240	20 to 27
3/8-16	240 to 300	27 to 34
7/16-14	420 to 540	47 to 61
Size	Pound- Feet	Newton metres
1/2-13	55 to 65	74 to 88
5/8-11	140 to 150	190 to 203

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Nom. SAE Dash Size	Tube OD	Thread Size	Pound- Inches	Newton metres	Thread Size	Pound- Inches	Newton metres
O-ring Face Seal End					O-ring Boss End Fitting or Lock Nut		
-4	1/4 inch 6.4 mm	9/16-18	120 to 144	14 to 16	7/16-20	204 to 240	23 to 27
-6	3/8 inch 9.5 mm	11/16-16	216 to 240	24 to 27	9/16-18	300 to 360	34 to 41
-8	1/2 inch 12.7 mm	13/16-16	384 to 480	43 to 54	3/4-16	540 to 600	61 to 68
					Thread Size	Pound- Feet	Newton metres
-10	5/8 inch 15.9 mm	1-14	552 to 672	62 to 76	7/8-14	60 to 65	81 to 88
Nom. SAE Dash Size	Tube OD	Thread Size	Pound- Feet	Newton metres	1-1/16-12	85 to 90	115 to 122
					1-3/16-12	95 to 100	129 to 136
-12	3/4 inch 19.0 mm	1-3/16-12	65 to 80	90 to 110	1-5/16-12	115 to 125	156 to 169
-14	7/8 inch 22.2 mm	1-3/16-12	65 to 80	90 to 110	1-5/8-12	150 to 160	203 to 217
-16	1.0 inch 25.4 mm	1-7/16-12	92 to 105	125 to 140	1-7/8-12	190 to 200	258 to 271
-20	1-1/4 inch 31.8 mm	1-11/16-12	125 to 140	170 to 190			
-24	1-1/2 inch 38.1 mm	2-12	150 to 180	200 to 254			

Section

1001

SAFETY, GENERAL INFORMATION / MAINTENANCE SCHEDULE

TABLE OF CONTENTS

SAFETY 3

GENERAL INFORMATION 5

 Cleaning 5

 Inspection 5

 Bearings 5

 Needle Bearings 5

 Gears 5

 Oil Seals, O-rings and Gaskets 5

 Shafts 5

 Service Parts 5

 Lubrication 5

MAINTENANCE SCHEDULE 6

SAFETY



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

M171B

To prevent injury always follow the Warning, Caution and Danger notes in this section and throughout the manual.

Put the warning tag shown below on the key for the key switch when servicing or repairing the machine. One warning tag is supplied with each machine. Additional tags are available from your service parts supplier.

Before servicing a machine, park the machine on hard level ground. Turn off the engine, apply the parking brake and remove the key from the key switch. Put blocks in front of and behind either the front or rear wheels.

DO NOT OPERATE

Reason _____

Signed by _____

DO NOT REMOVE THIS TAG!

See Other Side

Case Part No _____ Printed in U.S.A.

201L95



WARNING: Before starting engine study Operators Manual safety messages. Read all safety signs on machine. Clear the area of other persons. Learn and practice safe use of controls before operating. It is your responsibility to understand and follow manufacturers instructions on machine operation, service, and to observe pertinent laws and regulations. Operator and Service Manuals may be obtained from your equipment dealer.

M103A



WARNING: If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing.

M492



WARNING: When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.

M493



WARNING: Read the operators manual to familiarize yourself with the correct control functions.

M489



WARNING: When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure.

M494



WARNING: Operate the machine and equipment controls from the seat position only. Any other method could result in serious injury.

M490



WARNING: When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way.

M495



WARNING: This is one man machine, no riders allowed.

M491



WARNING: Always wear heat protective gloves to prevent burning your hands when handling heated parts.

SM121A



WARNING: Lower all attachments to the ground or use stands to safely support the attachments before you do any maintenance or service.

M496



WARNING: Hydraulic oil or diesel fuel leaking under pressure can penetrate the skin and cause infection or other injury.

To Prevent Personal Injury:

Relieve all pressure, before disconnecting fluid lines. Before applying pressure, make sure all connections are tight and components are in good condition.

Never use your hand to check for suspected leaks under pressure.

Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see your doctor immediately.

SM171A



WARNING: When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer.

M497



WARNING: When using a hammer to remove and install pivot pins or separate parts using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors).

M498



WARNING: Use suitable floor (service) jacks or chain hoist to raise wheels or tracks off the floor. Always block machine in placed with suitable safety stands.

M499



WARNING: When servicing or repairing the machine. Keep the shop floor and operators compartment and steps free of oil, water, grease, tools, etc. Use an oil absorbing material and or shop cloths as required. Use safe practices at all times.

M500



WARNING: Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in the Service Manual.

M501



WARNING: Engine exhaust fumes can cause death. If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension. Open the door and get outside air into the area.

M502



WARNING: When the battery electrolyte is frozen, the battery can explode if (1), you try to charge the battery, or (2), you try to jump start and run the engine. To prevent the battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured.

M503



WARNING: Batteries contain acid and explosive gas. Explosions can result from sparks, flames or wrong cable connections. To connect the jumper cables correctly to the battery of this machine see the Operators Manual. Failure to follow these instructions can cause serious injury or death.

M504

GENERAL INFORMATION

Cleaning

Clean all metal parts except bearings, in mineral spirits or by steam cleaning. Do not use caustic soda for steam cleaning. After cleaning, dry and put oil on all parts. Clean oil passages with compressed air.

Inspection

Check all parts when the parts are disassembled. Replace all parts that have excessive wear or are damaged. Small scoring or grooves can be removed with a hone or crocus cloth. Complete visual inspection for indications of wear, pitting and the replacement of parts necessary will prevent early failures.

Bearings

Clean bearings with a good clean solvent and permit to air dry. **DO NOT DRY BEARINGS WITH COMPRESSED AIR.** Check bearings for smooth easy action. If the bearing has a loose fit or rough action, the bearing must be replaced.

Needle Bearings

Before you press needle bearings into a bore, always remove any metal protrusions in the bore or the edge of the bore. Before you press bearings into position, put petroleum jelly on the inside and outside diameter of the bearing.

Gears

Check all gears for excessive wear or damage. Replace gears as necessary.

Oil Seals, O-rings and Gaskets

Always install new oil seals, O-rings and gaskets. Put petroleum jelly on seals and O-rings.

Shafts

Check all shafts for excessive wear or damage. Check the bearing and oil seal surfaces on the shafts for excessive wear or damage. Replace shafts as necessary.

Service Parts

Always install genuine Case service parts. When ordering refer to the Parts Catalog for the correct part number of the genuine Case replacement items. Failures due to the use of other than genuine Case replacement parts are not covered by warranty.

Lubrication

Use only the oils and lubrication specified in the Operators or Service Manual. Failures due to the use of non specified oils and lubricants are not covered by warranty.

Click on the image link below for the full version of the service manual

