
DX55

SSS - PIN Number Z7NFP1001 and Above
EHSS - PIN Number Z7NFS1001 and Above

DX60

REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCH	12
SECTION 21 - TRANSMISSION	13
SECTION 23 - FWD DRIVELINE	21
SECTION 25 - FWD FRONT AXLE	22
SECTION 27 - DIFFERENTIAL, REAR AXLE	23
SECTION 31 - POWER TAKE-OFF (PTO)	25
SECTION 33 - BRAKES	26
SECTION 35 - HYDRAULIC SYSTEM	27
SECTION 41 - STEERING	31
SECTION 44 - WHEELS AND TIRES	33
SECTION 50 - CLIMATE CONTROL	34
SECTION 55 - ELECTRICAL SYSTEM	38
SECTION 90 - PLATFORM	56

The following pages are the collation of the contents pages from each section and chapter of the DX55, DX60 Repair manual. Complete Repair part # 84140461.

The sections used through out all Case IH product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the DX55, DX60 Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87711137

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	3
	Personal Safety	3
	Machine Safety	3
	Information	3
	Safety	4
	Precautionary Statements	4
	The Tractor	4
	Servicing the Tractor	4
	Operating the Tractor	5
	Driving the Tractor	5
	Operating the PTO	6
	Diesel Fuel	6
	Safety Frame (ROPS)	6
	Safety Decals	7
	Instruction Decals	10
	Decal Placement Guide	13
	Ecology and the Environment	14
	Helpful Hints	14
	Universal Symbols	15
	General Information	16
	Minimum Hardware Tightening Torques	17
	Lubrication	19
	General Information	19
	Grease Fittings	19
	Recommended Lubricants	20
	Lubrication and Maintenance Chart DX55, DX60 — Front-wheel Drive	21
	Lubrication Fittings	22
	Diesel Fuel	22
	Fuel Usage Safety	22
	Specifications	23

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87711137

Chapter 1 - General Information (Continued)

CONTENTS

Section	Description	Page
	General Dimensions	32
	Wheel Tread Settings	35
	Front Axle (FWD) (Not Adjustable)	35
	Rear Axle (FWD)	35
	Liquid Ballast (Optional)	38
	Tire Pressure	38
	Rear Tire Liquid	38
	Ballast Weights (Per Tire)	38

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 1 - Engine Components

CONTENTS

Section	Description	Page
	Specifications	6
	Metric Bolt Torque Specifications	11
	Special Tools	11
	Compression Test and Tools	12
	Description of Operation - General Information	13
	Troubleshooting	14
	Cylinder Head and Valve Train Components	18
	Cylinder Block Assembly	18
	Engine	19
	Removal	19
	Installation	20
	Overhaul	21
	Engine	21

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Alternator	21
	Removal	21
	Cooling Fan and Pulley	21
	Removal	21
	Glow Plug and Connector	21
	Removal	21
	Nozzle/Holder	22
	Removal	22
	Fuel Injection Pipe	22
	Removal	22
	Injector	22
	Removal	22
	Water Pump	22
	Removal	22
	Cover/Intake Manifold/Exhaust Manifold	23
	Removal	23
	External Oil Pipe	23
	Removal	23
	Rocker Assembly	24
	Removal	24
	Cylinder Head	24
	Removal	24
	Tappets	24
	Removal	24
	Fuel Stop Solenoid	25
	Removal	25
	Timing Gear Cover	25
	Removal	25
	Timing Gears and Camshaft	27
	Removal	27
	Front End Plate	28
	Removal	28
	Oil Sump	28
	Removal	28

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Oil Suction Pipe and Strainer	29
	Removal	29
	Balancer Assembly	29
	Removal	29
	Connecting Rods, Bearings and Pistons, Rings	30
	Removal	30
	Flywheel	30
	Removal	30
	Backplate and Oil Seal	31
	Removal	31
	Crankshaft and Main Bearings	31
	Removal	31
	Rocker Arm Assembly	32
	Disassembly	32
	Inspection and Repair	32
	Timing Gear	33
	Inspection	33
	Camshaft	33
	Disassembly	33
	Inspection	33
	Oil Pump	34
	Disassembly	34
	Inspection	34
	Assembly	34
	Cylinder Head	35
	Disassembly	35
	Inspection and Repair	35
	Valves	36
	Valve Guides	36
	Valve Seat	37
	Valve Springs	38
	Rocker Arms	39
	Push Rods	40
	Rocker Arm Shaft	40
	Installation	40

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Cylinder Block	41
	Inspection and Repair	41
	Piston and Piston Rings	42
	Disassembly	42
	Inspection	42
	Connecting Rods	44
	Pistons, Rings and Connecting Rod	46
	Assembly	46
	Crankshaft Main Bearing and Thrust Washer	47
	Removal and Inspection	47
	Crankshaft Bearing (Bushing)	48
	Inspection	48
	Removal	49
	Replacement	49
	Crankshaft Main Bearing	50
	Installation	50
	Port Block	50
	Removal	50
	Installation	51
	Crankshaft and Bearing Holder	51
	Installation	51
	Relief Valve	52
	Installation	52
	Rear Oil Seal	52
	Installation	52
	Back Plate/Flywheel Housing	52
	Installation	52
	Flywheel	53
	Inspection and Repair	53
	Installation	53
	Pistons and Connecting Rods	53
	Installation	53

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Balancer Assembly	54
	Installation	54
	Balancer Shims	54
	Oil Suction Pipe and Suction Strainer	55
	Installation	55
	Oil Sump	55
	Installation	55
	Camshaft and Camshaft Gear	56
	Installation	56
	Idle Gear, Oil Pump and Injection Timing	56
	Installation	56
	Timing Gear Case	57
	Front Oil Seal and Steering Pump Seal	57
	Replacement	57
	Timing Gear Case	58
	Installation	58
	Crankshaft Pulley	59
	Installation	59
	Injection Pump	59
	Installation	59
	Head Gasket Selection	60
	Head Gasket Selection Chart	60
	Cylinder Head	60
	Assembly	60
	Valve Clearance Adjustment	61
	Head Cover	64
	Installation	64
	Intake/Exhaust Manifolds	64
	Installation	64
	External Oil Tube	65
	Installation	65

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Oil Pressure Switch	65
	Installation	65
	Alternator and Temperature Sender Switch	65
	Installation	65
	Glow Plug and Connector	65
	Installation	65
	Nozzle/Holder Assembly	66
	Installation	66
	Return Pipe and Injection Pipe	66
	Installation	66
	Hydraulic Oil Pump	66
	Installation	66
	Power Steering Pump	67
	Installation	67
	Turbo Charger	67
	Description of Operation - Engine Lubrication System	68
	Oil Filter	71
	Construction and Function	71
	Maintenance	71
	Oil Pump	71
	Removal	71
	Inspection	71
	Installation and Adjustment	72
	Engine Oil Pressure Check	73
	Oil Pressure Relief Valve	74
	Removal	74
	Installation	74
	Oil Consumption	74
	Description of Operation - Cooling System	75
	Maintenance	77

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Coolant	77
	Cooling System Capacity	77
	Radiator Cap	77
	Thermostat	78
	Water Pump	78
	Cooling Fan	78
	Radiator	79
	Removal	79
	Inspection	80
	Installation	81
	Water Pump	83
	Removal	83
	Inspection and Repair	84
	Installation	84
	Thermostat	85
	Removal	85
	Inspection and Repair	85
	Installation	86
	Oil Cooler	86
	Removal	86
	Installation	86

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 2 - Fuel Systems

CONTENTS

Section	Description	Page
	Specifications	2
	Standards for Adjusting the Injection Pump	2
	Special Tools	3
	Description of Operation	3
	Injection Pump	3
	Troubleshooting	5
	General	5
	Fuel Injectors	8
	Governor	9
	Engine Breather Valve	10
	Fuel Variation Mechanism	11
	Delivery Valve Assembly	12
	CTD (Compact Timing Device) Mechanism	12
	Pumping Elements	14
	Delivery Valves	16
	Injection Pump	17
	Removal	17
	Repair	19
	Installation	19
	Timing and Governor Adjustments	20
	Installation (New Pump or Drive Component)	20
	Spill-timing Procedure	21
	Bleeding The Fuel System	26
	Fuel Screw/High Idle Adjustment	26
	Governor	27
	Disassembly	29
	Assembly	30
	Adjustments	32
	Injectors	32
	Removal	33
	Disassembly	34
	Assembly/Adjustment	34

SECTION 10 - ENGINE

BOOK 1 - 87711137

Chapter 3 - Turbocharger

CONTENTS

Section	Description	Page
	Specifications	2
	Troubleshooting	2
	Lubrication	4
	Turbocharger	5
	Removal	5
	Inspection Before Disassembly	6
	Disassembly	6
	Inspection	9
	Turbine Shaft	10
	Bearings and Associated Parts	10
	Thrust Bearing	11
	Holes For Admitting Seal Ring	11
	Turbocharger Reassembly	11
	Installing the floating bearings	11
	Inserting the Shaft Into Bearing Casing	12
	Installing the Thrust Bearing	12
	Installing the Seal Plate	12
	Installing the Blower Wheel	13
	Installing the Turbine Casing	14
	Securing the Blower Casing to the Bearing Casing	14
	Installing the Waste Gate Controller Assembly	14
	Checking the Rotor for Movement	15
	Start-up Lubrication	15
	Intake Air System	15
	Exhaust System	16
	Initial Start of Turbocharger After Installation	16

SECTION 18 - CLUTCH

BOOK 1 - 87711137

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	Metric Bolt Torque Specifications	3
	Bolt Torques	3
	Special Tools	3
	Description of Operation	4
	Troubleshooting	5
	Overhaul	6
	Separating the Tractor at Clutch Housing/Engine	6
	Clutch	17
	Removal	17
	Inspection	18
	Clutch Release Bearing	19
	Inspection	19
	Clutch	19
	Installation	19
	Attaching the Tractor at Clutch Housing/Engine	21
	Clutch Pedal Adjustment	30
	Clutch Pedal Maximum Travel Adjustment (SSS Transmission)	31

SECTION 21 - TRANSMISSION

BOOK 2 - 87711138

Chapter 1 - EHSS Transmission

CONTENTS

Section	Description	Page
	Specifications	7
	Metric Bolt Torque Specifications	8
	Special Tools	9
	Description of Operation	11
	Powerflow (All Diagrams Shown With Forward Clutch Pack Engaged)	13
	Hydraulic Flow Diagrams	19
	Oil Pump For EHSS and PTO Clutch	19
	Neutral Position	20
	Forward Position	22
	Reverse Position	24
	Reverse Position - Inching Pedal Depressed	26
	Lube Cutoff Valve Operation	27
	Inching Pedal Depressed	27
	System Relief Valve Assembly	28
	System Relief Valve Assembly Operation	29
	EHSS Manifold Valve	29
	System Relief Valve	30
	Oil Cooler Relief Valve	30
	Oil Cooler Relief Valve Components	30
	Adjustment	31
	EHSS - System Relief Valve	31
	Oil Cooler and Lubrication Circuit Pressure Test	32
	EHSS Inching Pedal Potentiometer	33
	EHSS Control Valve Solenoid	35
	Solenoid Test	35
	Test Results	35
	Flow Test	35
	Neutral and Forward	35
	Reverse	36
	Troubleshooting	38
	Overhaul	40

SECTION 21 - TRANSMISSION

BOOK 2 - 87711138

Chapter 1 - EHSS Transmission (Continued)

CONTENTS

Section	Description	Page
	EHSS Control Valve Solenoid	40
	Disassembly	40
	Inspection	40
	Assembly	40
	EHSS Transmission	41
	Removal - Separating the Tractor at Clutch Housing/Engine	41
	Installation - Attaching the Tractor at Clutch Housing/Engine	49
	Clutch Housing	58
	Disassembly	58
	Main Transmission	59
	Disassembly - Separating the Transmission/Differential	59
	Shuttle Clutch Adapter/Input Shaft Retainer	61
	Input Shaft	62
	Reverse Idler Shaft and Gear	63
	Shift Rails	64
	Shuttle Clutch and Shaft	66
	PTO Shaft	68
	Countershaft	68
	Main Shaft	71
	Inspection	74
	Assembly	75
	Shuttle Clutch	84
	Shift Rails	85
	Reverse Idler	89
	Input Shaft	89
	Shuttle Clutch Adapter/Input Shaft Retainer	91
	Attaching The Transmission/Differential	91
	Clutch Housing	93
	Shuttle Clutch	95
	Disassembly	95
	Inspection	101
	Assembly	102

SECTION 21 - TRANSMISSION

BOOK 2 - 87711138

Chapter 1 - EHSS Transmission (Continued)

CONTENTS

Section	Description	Page
	Synchronizers	107
	Disassembly	108
	Inspection	114
	Synchronizers	115
	Assembly	116
	Complete EHSS Schematic	121
	1st or 2nd Gear, High and Forward Schematic	122
	1st or 2nd Gear Engaged High and Forward Engaged	123
	Current Flow	123
	Key Switch Placed in "RUN/ACC" Position	123
	Potentiometer	123
	With the Inching Pedal (not depressed)	123
	Controller Current Output	123
	Ground Sources	123
	1st or 2nd Gear, Low and Forward Schematic	124
	1st or 2nd Gear Engaged Low and Forward Engaged	125
	Current Flow	125
	Key Switch Placed in "RUN/ACC" Position	125
	Potentiometer	125
	With the Inching Pedal (not depressed)	125
	Controller Current Output	125
	Ground Sources	125
	1st or 2nd Gear, High and Reverse Schematic	126
	1st or 2nd Gear Engaged High and Reverse Engaged	127
	Current Flow	127
	Key Switch Placed in "RUN/ACC" Position	127
	Potentiometer	127
	With the Inching Pedal (not depressed)	127
	Controller Current Output	127
	Ground Sources	127
	1st or 2nd Gear, Low and Reverse Schematic	128
	1st or 2nd Gear Engaged Low and Reverse Engaged	129

Click on the image link below for the full version of the service manual

