
FARMALL 70, FARMALL 80, FARMALL 90, FARMALL 95 SERVICE MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCH	6
SECTION 21 - TRANSMISSIONS	7
SECTION 23 - DRIVE LINES	9
SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION	9
SECTION 27 - REAR AXLE AND TRANSMISSION	11
SECTION 31 - POWER TAKE-OFF	12
SECTION 33 - BRAKING SYSTEM	13
SECTION 35 - HYDRAULIC SYSTEM	14
SECTION 41 - STEERING	17
SECTION 44 - FRONT AXLE AND WHEELS (2WD)	18
SECTION 50 - CAB AIR CONDITIONING SYSTEM	19
SECTION 55 - ELECTRICAL SYSTEM	21
SECTION 90 - PLATFORM, CAB, BODYWORK	25

The following pages are the collation of the contents pages from each section and chapter of the Farmall 70, Farmall 80, Farmall 90, Farmall 95 Service manual. Complete Service part # 84253591.

The sections used through out all Case IH product Service manuals may not be used for each product. Each Service manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Service manual and which sections are in each book.

The sections listed above are the sections utilized for the Farmall 70, Farmall 80, Farmall 90, Farmall 95 Tractors.

SECTION 00 - GENERAL

BOOK 1 - 84253592

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Important Notice	3
	Shimming	3
	Rotating Shaft Seals	3
	O Rings	3
	Sealers	3
	Bearings	3
	Spring Pins	3
	Precautionary Notice	4
	Equipment Notice	4
	Spare Parts Notice	4
	General Notices	4
	Health and Safety	5
	Health and Safety Precautions	5
	General Workshop Tools and Equipment	11
	Legal Aspects	11
	Lubricants and Greases	11
	Precautionary Statements	15
	Personal Safety	15
	Machine Safety	15
	Information	15
	Safety	16
	The Tractor	16
	Driving the Tractor	16
	Operating the Tractor	16
	Operating the PTO	17
	Servicing the Tractor	17
	Diesel Fuel	18
	ROPS	18
	Ecology and the Environment	19
	Precautions	19
	Minimum Hardware Tightening Torques	20
	Consumables	23

SECTION 10 - ENGINE

BOOK 1 - 84253592

Chapter 1 - Engine (F5C)

CONTENTS

Section	Description	Page
	Special Tools	2
	Troubleshooting	3
	Overhaul	7
10 001 10	Removal	7
	Installation	25

SECTION 10 - ENGINE

BOOK 1 - 84253592

Chapter 2 - Engine (NEF)

CONTENTS

Section	Description	Page
	Specifications	4
	Torques	12
	Special Tools	14
	Sectional Views	15
	Troubleshooting	20
	Overhaul	24
10 001 10	Engine	24
	Removal	24
	Installation	40
10 001 53	Disassembly	42
	Engine Assembly on the Bench	56
	Fitting the Bushings	56
	Fitting the Tappets	57
	Fitting the Camshaft	57
	Fitting the Oil Nozzles	58

SECTION 10 - ENGINE

BOOK 1 - 84253592

Chapter 2 - Engine (NEF) (Continued)

CONTENTS

Section	Description	Page
	Fitting the Crankshaft	58
	Fitting the Connecting Rod - Piston Assembly	61
	Fitting the Piston Connecting Rod Assemblies in the Cylinder Liners	63
	Big End Cap Assembly	64
	Fitting the Thermostat Valve	65
	Fitting the Cylinder Head	66
	Fitting the Injectors	68
	Fitting the Rocker Arm Assembly	69
	Fitting the Timing Gear	69
	Fitting the Injection Pump	72
	Fitting the Additional Counterweights	73
	Fitting the Hydraulic Pump Drive Gear	74
	Fitting the Timing Gear Casing	74
	Fitting the Crankshaft Rear Seal	75
	Fitting the Flywheel	75
	Fitting the Oil Pump	76
	Fitting the Oil Sump	77
	Fitting the Crankshaft Front Seal	77
	Fitting the Crankshaft Front Pulley	77
	Fitting the Cooling System Union	78
	Fitting the Coolant Pump	78
	Fitting the Fan-alternator Pulley	79
	Fitting the Auxiliary Member Drive Belt	80
	Fitting the Exhaust Manifold - Turbine	81
	Fitting the Injector Feed Pipes	81
	Fitting the Priming Pump - Feed Pipes	81
	Fitting the Pipes Between the Fuel Supply and Injection Pumps, Pre-heating System and Tappet Cover	82
	Fitting the Starter Motor	82
10 102 70	Crankshaft Front Seal	83
	Removal	83
	Installation	86

SECTION 10 - ENGINE

BOOK 1 - 84253592

Chapter 2 - Engine (NEF) (Continued)

CONTENTS

Section	Description	Page
10 102 74	Crankshaft Rear Seal	86
	Removal	86
	Installation	88
10 106 12	Valve-rocker Arm Clearance	89
	Removal	89
	Installation	92
10 218 30	Engine Injector	93
	Removal	93
	Installation	94
10 246 14	Bosch Injection Pump	95
	Removal	95
	Installation	99
	Timing	100
	Fuel Circuit Air Bleeding	103
10 402 10	Coolant Pump	103
	Removal	103
	Installation	104
10 402 30	Thermostat Valve	105
	Removal	105
	Installation	106
10 406 10	Engine Radiator	107
	Removal	107
	Installation	111
10 414 10	Coolant Pump and Generator Drive Belts	112
	Adjusting Tension	112
	Checks, Measurements and Repairs	114
	Cylinder Block, Liners	114
	Checks and Measurements	114
	Crankshaft	117

SECTION 10 - ENGINE

BOOK 1 - 84253592

Chapter 2 - Engine (NEF) (Continued)

CONTENTS

Section	Description	Page
	Connecting Rods	119
	Bushings	119
	Checking Connecting Rods	120
	Checking Twisting	120
	Checking Bending	121
	Pistons	121
	Measuring the Piston Diameter	122
	Piston Pins	122
	Conditions for Correct Pin-piston Coupling	123
	Piston Rings	123
	Valves and Camshaft	124
	Valves	124
	Tappets	127
	Camshaft	128
	Cylinder Head	129
	Cylinder Head Mating Surface Check	129
	Cylinder Head Thickness	129
	Cylinder Head Hydraulic Seal Check	129
	Low Oil Pressure Indicator	130
	Functional Checks	130
	Oil Filter	130
	Replacement	130
	Cooling System	131
	Radiator - Flushing and Checks	131
	Coolant Thermometer - Testing	131
	Thermostat Valve - Replacement	131

SECTION 18 - CLUTCH

BOOK 1 - 84253592

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	5
	Special Tools	5
	Sectional Views	6
	Longitudinal Section of the Clutch VALEO	6
	Longitudinal Section of Clutch LUK 11"/11"	7
	Longitudinal Section of the LUK 12"/11" Clutch	7
	Troubleshooting	8
	Overhaul	9
18 110 10	Clutch	9
	Removal	9
	Installation	20
	Adjustments	21
	Minimum Permissible Dimensions After Refacing Parts Subject to Wear for VALEO Clutches	25
	Adjusting the VALEO Clutch	26
18 100 40	Adjustment of the Main Clutch Control Linkage	28
	PTO Clutch Linkage Adjustment (VALEO Clutch)	29
	PTO Clutch Linkage Adjustment (LUK Clutch) Single Lever PTO (Not for all markets)	30
	PTO Clutch Linkage Adjustment (LUK Clutch) Single Lever PTO (Not for all markets) (Only for Farmall 95 Model)	30

SECTION 21 - TRANSMISSIONS

BOOK 1 - 84253592

Chapter 1 - Mechanical Transmission (12 x 4)

CONTENTS

Section	Description	Page
	Specifications	2
	Torque Values	3
	Main Data - Gearbox and Range Gear	4
	Special Tools	5
	Sectional Views	7
	Description and Operation	10
	Troubleshooting	10

SECTION 21 - TRANSMISSIONS

BOOK 1 - 84253592

Chapter 2 - Reverser

CONTENTS

Section	Description	Page
21 000	Specifications	2
	Torque	2
	Special Tools	3
	Sectional Views	4
	Description and Operation	6
	Troubleshooting	6
	Overhaul	7
21 110 85	Clutch/Reverser Casing	7
	Disassembly	7
	Assembly	11

SECTION 21 - TRANSMISSIONS

BOOK 1 - 84253592

Chapter 3 - Reverser and Creeper Unit

CONTENTS

Section	Description	Page
21 000	Specifications	2
	Torque	3
	Special Tools	4
	Sectional Views	5
	Description and Operation	7
	Troubleshooting	7
	Overhaul	8
21 110 87	Clutch Casing - Synchronizer Reverser and Creeper Unit	8
	Disassembly	8
	Assembly	13

SECTION 23 - DRIVE LINES

BOOK 1 - 84253592

Chapter 1 - Drive Lines

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	3
	Special Tools	3
	Sectional Views	4
	Overhaul	5
23 101 26	Transmission Shafts and Guard	5
	Disassembly	5
	Assembly	5
23 101 40	Drive Gear Housing Assembly	6
	Removal	6
	Installation	7
23 101 42	Transfer Box, Unit Removed	8
	Disassembly	8
	Assembly	9

SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION

BOOK 2 - 84253593

Chapter 1 - Front Axle Mechanical Transmission

CONTENTS

Section	Description	Page
	Specifications	3
	Torque	6
	Special Tools	8
	Sectional Views	9
	Description and Operation	12
	Limited-Slip, Self-locking Differential Lock	12
	Operation	12
	No Spin Differential (Optional)	13
	Operation	14

SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION

BOOK 2 - 84253593

Chapter 1 - Front Axle Mechanical Transmission (Continued)

CONTENTS

Section	Description	Page
	Overhaul	15
25 100 30	Complete Front Axle	15
	Removal	15
	Installation	19
25 100 38	Front Axle	19
	Removal (Farmall 80/90/95)	19
	Installation (Farmall 80/90/95)	31
	Removal (Farmall 70)	32
	Installation (Farmall 70)	32
	Front Axle Differential With No Spin	33
	Removal	33
	Disassembly	33
	Assembly	33
	Adjustments	34
	Steering Knuckle Pins and Bearings	34
	Stub Axle Adjustment	35
	Wheel Hub Bearing Adjustment	37
	First Class Axle Mod. Farmall 70	37
	Second Class Axle Mod. Farmall 80, Farmall 90 and Farmall 95	38
	Bevel Drive Adjustments	39
	Adjustment of the Preload of the Pinion Shaft Bearings	39
	Determining the Thickness of the Drive Pinion Position Adjustment Shim	40
	Examples (Farmall 70)	41
	Adjustment of the Crown Wheel Bearings and Checking the Backlash Between the Pinion and Crown Wheel	42
	Front Axle Differential Adjustment	46
	Front Axle Differential With Limited-Slip Unit	47
	Removal	47
	Disassembly	47
	Installation	48
	Checking the Alignment of Steering Drive Wheels	49

SECTION 27 - REAR AXLE AND TRANSMISSION

BOOK 2 - 84253593

Chapter 1 - Rear Axle and Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	4
	Special Tools	6
	Sectional Views	7
	Description and Operation	8
	Troubleshooting	10
	Overhaul	11
21 118 10 - 21 118 12	Rear Transmission - Gearbox Case	11
	Removal	11
	Installation	41
21 118 85	Transmission - Gearbox	42
	Removal	42
	Installation	47
	Final Drive	51
	Removal	51
	Disassembly (Cover)	51
	Disassembly (Housing)	53
	Assembly	53
	Adjustments	54
	Transmission - Gearbox Case	54
	Adjusting Gearbox Driving Shaft Axial Clearance	54
	Adjusting the Position of the Differential Lock Engagement Sleeve	55
	Bevel Gear Pair	56
	Determining the Bevel Pinion Positioning Adjustment Ring	56
	Adjusting the Taper-Roller Bearings for Pinion Shaft	59
	Adjusting the Ring Bevel Gear Bearings and Checking the Clearance Between the Teeth of the Bevel Gear Pair	60
	Differential Pinion and Side Gear Backlash Adjustment	63

SECTION 31 - POWER TAKE-OFF

BOOK 2 - 84253593

Chapter 1 - Mechanical Power Take-off

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	5
	Torque	6
	Sectional Views	7
	Description of Operation	12
	Mechanical PTO	12
	Independent PTO	12
	Ground Speed PTO	13
	PTO Speed Selector Lever (2)	13
	Single Lever Power Take-Off - (Optional)	14
	Troubleshooting	14
	Overhaul	15
31 112 20	540/750 Mechanical PTO	15
	Removal	15
	Installation	18
31 112 45 to 31 112 48	Disassembly	19
	Assembly	22
31 114	540/1000 Mechanical PTO (Interchangeable PTO Shaft - N.A. Version)	22
	Disassembly	22
	Assembly	27

SECTION 33 - BRAKING SYSTEM

BOOK 2 - 84253593

Chapter 1 - Braking System

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	3
	Sectional Views	4
	Brakes	5
	Special Tools	8
	Description of Operation	8
	Service Brakes	8
	Parking Brake	8
	Troubleshooting	9
	Overhaul	10
33 202 60	Service Brake	10
	Removal	10
	Installation	15
33 202 50	Hydraulic Front Brake Pump (Optional)	17
	Removal	17
	Installation	20
33 202 50	Hydraulic Brake Slave Cylinder	20
	Removal	20
	Installation	21
33 202 04	Hydraulic Front Brake System (Optional)	21
	Air Bleeding	21
	Adjustments	23
33 120 08	Service Brake Pedals	23
	Adjusting the Height	23
33 110 08	Hand Brake Control	25
	Adjusting Travel	25

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84253593

Chapter 1 - Rear Mechanical Hydraulic Lift

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Torque	6
	Special Tools	7
	Sectional Views	8
	Description and Operation	10
	Hydraulic Lift Circuit	10
	Arm Lift Phase	11
	Neutral Phase	12
	Arm Lowering Phase	13
	Troubleshooting	14
	Overhaul	16
35 110 30	Rear Hydraulic Lift Assembly	16
	Removal	16
	Installation	23
35 110 40 - 42 - 46	Disassembly	24
	Assembly	27
	Adjusting The Lift	29
	Position Control	30
	Maximum Height of the Lift Arms	31
	Draft Control	32
35 110 08	Adjusting Linkages	37
	Position Control Linkage	37
	Draft Control Linkage	37
	Fast Raise/Lower Device	38
35 110 30	Lift Pressure Relief Valve	39
35 110 32	Calibration	40
35 110 14	Lift Control Valve Block, Detached	42
	Disassembly	42
	Assembly	46
35 101 10	Hydraulic Lift Control Oil Pump	47
	Disassembly	47
	Assembly	48

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84253593

Chapter 2 - Open Center System Auxiliary Control Valves

CONTENTS

Section	Description	Page
35 000	Specifications	2
	Special Tools	2
	Sectional Views	3
	Description and Operation	4
	Operating Stages of Auxiliary Control Valve for Operation of a Double-acting Cylinder with Automatic Detent Release and Float Position	4
	Float Control Operation	4
	Lifting	5
	Lowering	5
	Operating Stages of Auxiliary Control Valve for Operation of a Double-acting Cylinder . . .	6
	Lifting	6
	Lowering	6
	Operating Stages of Auxiliary Control Valve for Operation of a Single Acting Cylinder . . .	6
	Lifting	6
	Lowering	7
	Operating Stages of Auxiliary Control Valve Operating a Double-acting Cylinder with Automatic Detent Release	7
	Lifting	7
	Lowering	8
	Overhaul	9
35 204 46	Convertible Single/Double-acting Auxiliary Control Valve	9
	Disassembly - Assembly (Valves Removed from Tractor)	9
	Convertible Single/Double-acting Auxiliary Control Valve with Float Control and Detent Release	10
	Disassembly - Assembly	10
	Double-acting Auxiliary Control Valve with Float Control and Automatic Detent Release	19
	Disassembly - Assembly	19
	Spool Binding Test	19
	Control Valve Spool binding Test	19
	Spool Leakage Test	20
	Valve Leakage Test	20
	Adjustment of the Automatic Detent Release Pressure	21

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84253593

Chapter 3 - Trailer Brake Auxiliary Control Valve

CONTENTS

Section	Description	Page
	Sectional View	2
	Description and Operation	2
	Hydraulic Diagram of Trailer Brake Auxiliary Control Valve	3
	Description and Operation of Valve Phases	4
	Trailer Brakes Off	4
	Start of Braking	4
	Braking	5
	Trailer Brake Remote Control Valve Linkage Adjustment	6

SECTION 41 - STEERING

BOOK 3 - 84253594

Chapter 1 - Steering

CONTENTS

Section	Description	Page
41 000	Specifications	2
	Torque	4
	Sectional Views	5
	Special Tools	8
	Description and Operation	9
	Steering to the Right	9
	Steering to the Left	9
	Steering to the Right Manually	9
	Steering to the Left Manually	9
	Troubleshooting	11
	Overhaul	13
41 204 30	Hydrostatic Steering Control Valve	13
	Removal	13
	Installation	16
41 204 34	Disassembly	16
	Assembly	23
41 204 38	Bench Testing	35
	Hydrostatic Steering Oil Pump	38
	Disassembly	39
	Assembly	40
41 216 20	Steering Cylinder (2WD)	40
	Removal - Refitting	40
	Steering Cylinder (FWD)	42
	Removal - Refitting	42

SECTION 44 - FRONT AXLE AND WHEELS (2WD)

BOOK 3 - 84253594

Chapter 1 - Axle and Wheels

CONTENTS

Section	Description	Page
44 000	Specifications	2
	Torque	5
	Special Tools	7
	Troubleshooting	7
	Overhaul	8
44 101 30	Front Axle	8
	Removal	8
	Installation	11
44 101 22	Axle Wheel Hub	12
	Removal	12
	Installation	17
44 101 46	Stub Axle	21
	Removal	21
	Installation	24
	Adjustments	26
44 101 80	Toe-In	27

SECTION 50 - CAB AIR CONDITIONING SYSTEM

BOOK 3 - 84253594

Chapter 1 - Air Conditioning System

CONTENTS

Section	Description	Page
50 000	Safety	3
	Specifications	4
	Special Tools	5
	Description of Operation	6
	Cab Heating and Ventilation Controls	8
	Ventilation	8
	Fan	8
	Air Filter	8
	Heating	9
	Temperature Control Knob	9
	Ignition Switch	9
	Switching on the Air Conditioning and Temperature Control	10
	Air Conditioning and Temperature Control Button	10
	Heating Control Knob	10
	3-Speed Fan Control Knob	10
	Use of the Air Conditioning System	11
	Switching On the Air Conditioning	11
	Adjustment	11
	Switching Off the Air Conditioning System	11
	Components of the Air Conditioning System	12
	Compressor	12
	Condenser	13
	Receiver/Dryer	14
	Thermostatic Expansion Valve	15
	Air Conditioner Temperature Cycling Control Switch	16
	Thermostatic Switch (ANTIFROST)	16
	Evaporator	17
	Refrigerant Recovery-Recycling and Evacuation-Charging Stations	18
	Recovery and Recycling Station (380000559)	18
	Maintenance	18
	Evacuation/Charging Station (380000558)	19

Click on the image link below for the full
version of the service manual

