
FARMALL 55, FARMALL 60 SERVICE MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCH	12
SECTION 21 - TRANSMISSION	13
SECTION 23 - FWD DRIVELINE	21
SECTION 25 - FWD FRONT AXLE	22
SECTION 27 - DIFFERENTIAL, REAR AXLE	23
SECTION 31 - POWER TAKE-OFF (PTO)	24
SECTION 33 - BRAKES	25
SECTION 35 - HYDRAULIC SYSTEM	26
SECTION 41 - STEERING	30
SECTION 44 - WHEELS AND TIRES	32
SECTION 50 - CLIMATE CONTROL	33
SECTION 55 - ELECTRICAL SYSTEM	37
SECTION 90 - PLATFORM	55

The following pages are the collation of the contents pages from each section and chapter of the Farmall 55, Farmall 60 Service manual. Complete Service part # 84257441.

The sections used through out all Case IH product Service manuals may not be used for each product. Each Service manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Service manual and which sections are in each book.

The sections listed above are the sections utilized for the Farmall 55, Farmall 60 Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 84257442

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	3
	Personal Safety	3
	Machine Safety and Information	3
	Safety	4
	Precautionary Statements	4
	The Tractor	4
	Servicing the Tractor	4
	Operating the Tractor	5
	Driving the Tractor	5
	Operating the PTO	6
	Diesel Fuel	6
	Safety Frame (ROPS)	6
	Ecology and the Environment	7
	Helpful Hints	7
	Universal Symbols	8
	General Information	9
	Minimum Hardware Tightening Torques	10
	Lubrication	12
	General Information	12
	Grease Fittings	12
	Chains	12
	Lubrication and Maintenance Chart	
	Case IH Farmall 55, Farmall 60 — Front-Wheel Drive	14
	Lubrication Fittings	15
	Diesel Fuel	15
	Fuel Usage Safety	15
	Specifications	16
	General Dimensions	25
	Wheel Tread Settings	28
	Front Axle (FWD) (Not Adjustable)	28
	Rear Axle (FWD)	28

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 84257442

Chapter 1 - General Information (Continued)

CONTENTS

Section	Description	Page
	Liquid Ballast (Optional)	31
	Tire Pressure	31
	Rear Tire Liquid	31
	Ballast Weights (Per Tire)	31

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 1 - Engine Components

CONTENTS

Section	Description	Page
	Specifications	7
	Metric Bolt Torque Specifications	12
	Special Tools	12
	Compression Test and Tools	13
	Troubleshooting	14
	Description of Operation - General Information	18
	Cylinder Head and Valve Train Components	19
	Cylinder Block Assembly	19
	Overhaul	20
	Engine	20
	Removal	20
	Installation	21
	Alternator and Temperature Sending Switch	22
	Removal	22
	Cooling Fan and Pulley	22
	Removal	22

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Glow Plug and Connector	22
	Removal	22
	Fuel Injection Tubing	23
	Removal	23
	Fuel Injector	23
	Removal	23
	Water Pump	23
	Removal	23
	Cover/Intake Manifold/Exhaust Manifold	24
	Removal	24
	External Oil Tube	24
	Removal	24
	Rocker Assembly	25
	Removal	25
	Cylinder Head	25
	Removal	25
	Tappets	25
	Removal	25
	Fuel Stop Solenoid	26
	Removal	26
	Timing Gear Cover	26
	Removal	26
	Timing Gears and Camshaft	28
	Removal	28
	Front End Plate	29
	Removal	29
	Oil Sump	29
	Removal	29
	Oil Suction Tube and Strainer	30
	Removal	30
	Balancer Assembly	30
	Removal	30

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Connecting Rods, Bearings and Pistons, Rings	31
	Removal	31
	Flywheel	31
	Removal	31
	Backplate and Oil Seal	32
	Removal	32
	Crankshaft and Main Bearings	32
	Removal	32
	Rocker Arm Assembly	33
	Disassembly	33
	Inspection and Repair	33
	Timing Gear	34
	Inspection	34
	Camshaft	34
	Disassembly	34
	Inspection	34
	Oil Pump	35
	Disassembly	35
	Inspection	35
	Assembly	35
	Cylinder Head	36
	Disassembly	36
	Inspection and Repair	36
	Valves	37
	Inspection	37
	Valve Guides	37
	Inspection	37
	Valve Seat	38
	Inspection	38
	Valve Springs	39
	Inspection	39

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Rocker Arms	40
	Inspection	40
	Push Rods	41
	Inspection	41
	Rocker Arm Shaft	41
	Installation	41
	Cylinder Block	42
	Inspection and Repair	42
	Piston and Piston Rings	43
	Disassembly	43
	Inspection	43
	Connecting Rods	45
	Inspection and Repair	45
	Pistons, Rings and Connecting Rod	47
	Assembly	47
	Crankshaft Main Bearing and Thrust Washer	48
	Removal and Inspection	48
	Crankshaft Bearing (Bushing)	49
	Inspection	49
	Removal	50
	Replacement	50
	Crankshaft Main Bearing	51
	Installation	51
	Port Block	51
	Removal	51
	Installation	52
	Crankshaft and Bearing Holder	52
	Installation	52
	Relief Valve	53
	Installation	53
	Rear Oil Seal	53
	Installation	53

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Back Plate	53
	Installation	53
	Flywheel	54
	Inspection and Repair	54
	Installation	54
	Pistons and Connecting Rods	54
	Installation	54
	Balancer Assembly	55
	Installation	55
	Balancer Shims	55
	Oil Suction Tube and Suction Strainer	56
	Installation	56
	Oil Sump	56
	Installation	56
	Camshaft and Camshaft Gear	57
	Installation	57
	Idler Gear, Oil Pump and Injection Timing	57
	Installation	57
	Timing Gear Case	58
	Front Oil Seal and Steering Pump Seal	58
	Replacement	58
	Timing Gear Case	59
	Installation	59
	Crankshaft Pulley	60
	Installation	60
	Injection Pump	60
	Installation	60
	Head Gasket Selection	61
	Head Gasket Selection Chart	61
	Cylinder Head	61
	Assembly	61
	Valve Clearance Adjustment	62

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Head Cover	65
	Installation	65
	Intake/Exhaust Manifolds	65
	Installation	65
	External Oil Tube	66
	Installation	66
	Oil Pressure Switch	66
	Installation	66
	Water Pump and Cooling Fan	66
	Installation	66
	Alternator and Temperature Sender Switch	66
	Installation	66
	Glow Plug and Connector	66
	Installation	66
	Fuel Injector	67
	Installation	67
	Fuel Injection Tubing	67
	Installation	67
	Hydraulic Oil Pump	67
	Installation	67
	Power Steering Pump	68
	Installation	68
	Turbo Charger	68
	Description of Operation - Engine Lubrication System	69
	Oil Filter	72
	Construction and Function	72
	Maintenance	72
	Oil Pump	72
	Removal	72
	Inspection	72
	Installation and Adjustment	73

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 1 - Engine Components (Continued)

CONTENTS

Section	Description	Page
	Engine Oil Pressure Check	74
	Oil Pressure Relief Valve	75
	Removal	75
	Installation	75
	Oil Consumption	75
	Description of Operation - Cooling System	76
	Maintenance	78
	Coolant	78
	Cooling System Capacity	78
	Radiator Cap	78
	Thermostat	79
	Water Pump	79
	Cooling Fan	79
	Radiator	80
	Removal	80
	Inspection	81
	Installation	82
	Water Pump	84
	Removal	84
	Inspection and Repair	85
	Installation	85
	Thermostat	86
	Removal	86
	Inspection and Repair	86
	Installation	87
	Oil Cooler	87
	Removal	87
	Installation	87

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 2 - Fuel Systems

CONTENTS

Section	Description	Page
	Specifications	2
	Standards for Adjusting the Injection Pump	2
	Special Tools	3
	Description of Operation	3
	Injection Pump	3
	Troubleshooting	5
	General	5
	Fuel Injectors	8
	Governor	9
	Engine Breather Valve	10
	Description of Operation	11
	Fuel Variation Mechanism	11
	Delivery Valve Assembly	12
	CTD (Compact Timing Device) Mechanism	12
	Pumping Elements	14
	Delivery Valves	16
	Overhaul - Fuel System	17
	Injection Pump	17
	Removal	17
	Repair	19
	Installation	19
	Installation (New Pump or Drive Component)	20
	Injection Pump Timing	21
	Fuel Flow Chart	21
	Bleeding the Fuel System	22
	Fuel Screw/High Idle Adjustment	22
	Governor	23
	Disassembly	25
	Assembly	26
	Adjustments	28
	Injectors	28
	Removal	29
	Disassembly	30
	Assembly/Adjustment	30

SECTION 10 - ENGINE

BOOK 1 - 84257442

Chapter 3 - Turbocharger

CONTENTS

Section	Description	Page
	Specifications	2
	Troubleshooting	2
	Lubrication	4
	Overhaul	5
	Turbocharger	5
	Removal	5
	Inspection Before Disassembly	6
	End Play Movement	6
	Radial Movement	6
	Disassembly	6
	Inspection	9
	Turbine Shaft	10
	Bearings and Associated Parts	10
	Thrust Bearing	11
	Holes For Admitting Seal Ring	11
	Turbocharger Reassembly	11
	Installing the Floating Bearings	11
	Inserting the Shaft Into Bearing Casing	12
	Installing the Thrust Bearing	12
	Installing the Seal Plate	12
	Installing the Blower Wheel	13
	Installing the Turbine Casing	14
	Securing the Blower Casing to the Bearing Casing	14
	Installing the Waste Gate Controller Assembly	14
	Checking the Rotor for Movement	15
	Start-up Lubrication	15
	Intake Air System	15
	Exhaust System	16
	Initial Start of Turbocharger After Installation	16

SECTION 18 - CLUTCH

BOOK 1 - 84257442

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	Metric Bolt Torque Specifications	3
	Bolt Torques	3
	Special Tools	3
	Description of Operation	4
	Troubleshooting	5
	Overhaul	6
	Separating the Tractor at Clutch Housing/Engine	6
	Preparation	6
	Removal	6
	Clutch	16
	Removal	16
	Inspection	17
	Clutch Release Bearing	18
	Inspection	18
	Clutch	18
	Installation	18
	Attaching the Tractor at Clutch Housing/Engine	20
	Installation	20
	Clutch Pedal Adjustment	29
	Clutch Pedal Maximum Travel Adjustment (SSS Transmission)	30

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 1 - EHSS Transmission

CONTENTS

Section	Description	Page
	Specifications	7
	Metric Bolt Torque Specifications	8
	Special Tools	9
	Description of Operation	11
	Powerflow (All Diagrams Shown With Forward Clutch Pack Engaged)	13
	Hydraulic Flow Diagrams	19
	Oil Pump For EHSS and PTO Clutch	19
	Neutral Position	20
	Forward Position	22
	Reverse Position	24
	Reverse Position - Inching Pedal Depressed	26
	Lube Cutoff Valve Operation	27
	Inching Pedal Depressed	27
	System Relief Valve Assembly	28
	System Relief Valve Assembly Operation	29
	EHSS Manifold Valve	29
	System Relief Valve	30
	Oil Cooler Relief Valve	30
	Oil Cooler Relief Valve Components	30
	Adjustment	31
	EHSS - System Relief Valve	31
	Oil Cooler and Lubrication Circuit Pressure Test	33
	EHSS Inching Pedal Potentiometer	34
	EHSS Control Valve Solenoid	36
	Solenoid Test	36
	Test Results	36
	Flow Test	36
	Neutral and Forward	36
	Reverse	37
	Troubleshooting	39
	Overhaul	41

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 1 - EHSS Transmission (Continued)

CONTENTS

Section	Description	Page
	EHSS Control Valve Solenoid	41
	Disassembly	41
	Inspection	41
	Assembly	41
	EHSS Transmission	42
	Removal - Separating the Tractor at Clutch Housing/Engine	42
	Installation - Attaching the Tractor at Clutch Housing/Engine	50
	Clutch Housing	59
	Disassembly	59
	Main Transmission	60
	Disassembly - Separating the Transmission/Differential	60
	Shuttle Clutch Adapter/Input Shaft Retainer	62
	Input Shaft	63
	Reverse Idler Shaft and Gear	64
	Shift Rails	65
	Shuttle Clutch and Shaft	67
	PTO Shaft	69
	Countershaft	69
	Main Shaft	72
	Inspection	75
	Assembly	76
	Shuttle Clutch	86
	Shift Rails	86
	Reverse Idler	90
	Input Shaft	90
	Shuttle Clutch Adapter/Input Shaft Retainer	92
	Attaching The Transmission/Differential	92
	Clutch Housing	94
	Shuttle Clutch	96
	Disassembly	96
	Inspection	102
	Assembly	103

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 1 - EHSS Transmission (Continued)

CONTENTS

Section	Description	Page
	Synchronizers	108
	Disassembly	109
	Inspection	115
	Synchronizers	116
	Assembly	117
	Complete EHSS Schematic	122
	1st or 2nd Gear, High and Forward Schematic	123
	1st or 2nd Gear Engaged High and Forward Engaged	124
	Current Flow	124
	Key Switch Placed in "RUN/ACC" Position	124
	Potentiometer	124
	With the Inching Pedal (not depressed)	124
	Controller Current Output	124
	Ground Sources	124
	1st or 2nd Gear, Low and Forward Schematic	125
	1st or 2nd Gear Engaged Low and Forward Engaged	126
	Current Flow	126
	Key Switch Placed in "RUN/ACC" Position	126
	Potentiometer	126
	With the Inching Pedal (not depressed)	126
	Controller Current Output	126
	Ground Sources	126
	1st or 2nd Gear, High and Reverse Schematic	127
	1st or 2nd Gear Engaged High and Reverse Engaged	128
	Current Flow	128
	Key Switch Placed in "RUN/ACC" Position	128
	Potentiometer	128
	With the Inching Pedal (not depressed)	128
	Controller Current Output	128
	Ground Sources	128
	1st or 2nd Gear, Low and Reverse Schematic	129

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 1 - EHSS Transmission (Continued)

CONTENTS

Section	Description	Page
	1st or 2nd Gear Engaged Low and Reverse Engaged	130
	Current Flow	130
	Key Switch Placed in "RUN/ACC" Position	130
	Potentiometer	130
	With the Inching Pedal (not depressed)	130
	Controller Current Output	130
	Ground Sources	130
	3rd or 4th Gear, High and Forward Schematic	131
	3rd or 4th Gear Engaged High and Forward Engaged	132
	Current Flow	132
	Key Switch Placed in "RUN/ACC" Position	132
	Potentiometer	132
	With the Inching Pedal (not depressed)	132
	Controller Current Output	132
	Ground Sources	132
	3rd or 4th Gear, Low and Forward Schematic	133
	3rd or 4th Gear Engaged Low and Forward Engaged	134
	Current Flow	134
	Key Switch Placed in "RUN/ACC" Position	134
	Potentiometer	134
	With the Inching Pedal (not depressed)	134
	Controller Current Output	134
	Ground Sources	134
	3rd or 4th Gear, High and Reverse Schematic	135
	3rd or 4th Gear Engaged High and Reverse Engaged	136
	Current Flow	136
	Key Switch Placed in "RUN/ACC" Position	136
	Potentiometer	136
	With the Inching Pedal (not depressed)	136
	Controller Current Output	136
	Ground Sources	136
	3rd or 4th Gear, Low and Reverse Schematic	137

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 1 - EHSS Transmission (Continued)

CONTENTS

Section	Description	Page
	3rd or 4th Gear Engaged Low and Reverse Engaged	138
	Current Flow	138
	Key Switch Placed in "RUN/ACC" Position	138
	Potentiometer	138
	With the Inching Pedal (not depressed)	138
	Controller Current Output	138
	Ground Sources	138
	EHSS Controller Activation	139
	Current Flow	139
	Key Switch Placed in "RUN/ACC" Position	139
	Controller Activation	139
	Potentiometer	139
	With the Inching Pedal (free position)	139
	Ground Sources	139
	Modulation Time Chart	141
	EHSS Controller	142
	Removal	142
	EHSS Controller Testing	143
	1st or 2nd Gear, High and Forward Circuit	143
	1st or 2nd Gear, Low and Forward Circuit	143
	1st or 2nd Gear, High and Reverse Circuit	143
	1st or 2nd Gear, Low and Reverse Circuit	144
	3rd or 4th Gear, High and Forward Circuit	144
	3rd or 4th Gear, Low and Forward Circuit	144
	3rd or 4th Gear, High and Reverse Circuit	145
	3rd or 4th Gear, Low and Reverse Circuit	145
	Activation Circuit	145
	Installation	146
	Shuttle Switch (Forward/Reverse)	146
	Removal	147
	Testing	148
	Installation	148

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 1 - EHSS Transmission (Continued)

CONTENTS

Section	Description	Page
	Transmission Modulation Switches	149
	Removal (ALL Switches)	149
	Main 1-2 Switch (ball located behind switch)	149
	Testing	149
	Main 1-2 Switch	150
	“HIGH” and “LOW” Range Switches	150
	Installation (ALL Switches)	150
	Troubleshooting Shiftability	151
	Description of Operation	151
	Breakout Box Connection to Tractor	152
	Test Procedures – Switches	153
	High Range Switch	154
	Low Range Switch	155
	Neutral, 1st and 2nd Gear Switch	156
	Shuttle Switch (F-N-R)	158
	Neutral Test	159
	Forward Test	160
	Reverse Test	160
	Solenoid Test-EHSS Control Valve	160
	Potentiometer Function	161
	Adjustment – EHSS Inching Pedal Linkage	161
	Adjustment – Potentiometer	163
	Modulation Explanation	163
	Modulation Time Chart	163
	Modulation Time-Test Procedure	164
	Wiring Diagram – EHSS Circuit	165
	General Overall Troubleshooting	166
	EHSS Electrical Troubleshooting (Range)	166
	EHSS Electrical Troubleshooting (Main Gear and Shuttle)	167
	EHSS Electrical Troubleshooting (Potentiometer)	168
	EHSS Concern Report	169

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 2 - SSS 12x12 Gear Transmission

CONTENTS

Section	Description	Page
	Specifications	3
	Metric Bolt Torque Specifications	4
	Special Tools	5
	Description of Operation	5
	Powerflow	8
	Troubleshooting	12
	Overhaul	13
	Clutch Housing	13
	Disassembly	13
	Main Transmission Input Shaft Retainer	16
	Disassembly	16
	Shuttle Shaft Retainer	17
	Input Shaft	18
	Disassembly	18
	Reverse Idler Shaft and Gear	18
	Disassembly	18
	Shift Rails	19
	Disassembly	19
	Countershaft	21
	Disassembly	21
	Main Shaft	24
	Disassembly	24
	Shuttle Gears	27
	Disassembly	27
	Inspection	30
	Main Transmission Range Gear Shifter	31
	Assembly	31
	Main Shaft	34
	Assembly	34
	Range Gears	38
	Assembly	38

SECTION 21 - TRANSMISSION

BOOK 2 - 84257443

Chapter 2 - SSS 12x12 Gear Transmission (Continued)

CONTENTS

Section	Description	Page
	Range Gear Shift Fork	40
	Assembly	40
	Countershaft	41
	Assembly	41
	PTO Shaft	43
	Assembly	43
	Shift Rails	44
	Assembly	44
	Reverse Idler	48
	Assembly	48
	Input Shaft	49
	Assembly	49
	Input Shaft Retainer	50
	Assembly	50
	Attaching the Transmission / Differential	51
	Clutch Housing	54
	Assembly	54
	Synchronizers – Main Gears	56
	Main Transmission Gears/Synchronizer	57
	Disassembly	57
	Synchronizers	63
	Inspection	63
	Main Transmission Gears/Synchronizer	65
	Assembly	65
	Synchronizers – Shuttle Gears	70
	Transmission Shuttle Gears/Synchronizer	71
	Disassembly	71
	Synchronizers	75
	Inspection	75
	Main Transmission Gears/Synchronizer	77
	Assembly	77

Click on the image link below for the full
version of the service manual

