



MDB1965A

# **JX1060V - JX1070V - JX1075V - JX1070N - JX1075N TRACTORS SERVICE MANUAL**

## **SECTIONS**

<b>GENERAL GUIDELINES</b> .....	<b>00</b>
<b>ENGINE</b> .....	<b>10</b>
<b>CLUTCH</b> .....	<b>18</b>
<b>TRANSMISSIONS</b> .....	<b>21</b>
<b>DRIVE LINES</b> .....	<b>23</b>
<b>FRONT MECHANICAL TRANSMISSION</b> .....	<b>25</b>
<b>REAR MECHANICAL TRANSMISSION</b> .....	<b>27</b>
<b>POWER TAKE-OFF</b> .....	<b>31</b>
<b>BRAKES</b> .....	<b>33</b>
<b>HYDRAULIC SYSTEMS</b> .....	<b>35</b>
<b>STEERING</b> .....	<b>41</b>
<b>AXLE AND WHEELS</b> .....	<b>44</b>
<b>CAB AIR CONDITIONING SYSTEM</b> .....	<b>50</b>
<b>ELECTRICAL SYSTEM</b> .....	<b>55</b>
<b>CAB</b> .....	<b>90</b>

**T E C H N I C A L   S U P P O R T**

## INTRODUCTION

- ◇ *This manual is divided into sections identified by two-figure numbers and each section has independent page numbering.  
For easy reference, these sections have the same numbers and names as the Repairs Rate Book sections.*
- ◇ *The different sections can easily be found by consulting the table of contents on the following pages.*
- ◇ *The document number of the manual and the edition/update dates are given at the bottom of each page.*
- ◇ *Pages updated in the future will be identified by the a document number and by the corresponding issue date.  
These pages will be supplemented by a reprint of the updated contents page.*
- ◇ *The information contained in this manual was current on the date printed on each section. As CASE IH constantly improves its product range, some information may be out of date subsequent to modifications implemented for technical or commercial reasons, or to meet legal requirements in different countries.  
In the event of conflicting information, consult the CASE IH Sales and Service Departments.*

## IMPORTANT WARNINGS

- ◇ *All maintenance and repair work described in this manual must be performed exclusively by CASE IH service technicians, in strict accordance with the instructions given and using any specific tools necessary.*
- ◇ *Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.*
- ◇ *The Manufacturer and all organisations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer.  
In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.*

TEXT AND ILLUSTRATIONS ARE THE PROPERTY OF  
CNH ITALIA S.p.A.



No part of the text or illustrations  
may be reproduced

PRINTED IN ITALY

**CNH ITALIA S.p.A. - Viale delle Nazioni, 55 - 41100 MODENA - Italy**  
TECHNICAL SUPPORT - Technical Information  
Print No. **6-62730** - 04 - 2004 - 200

## CONTENTS VOLUME 1

	Page	Date		Page	Date
<b>00 - GENERAL GUIDELINES</b>			Engine Disassembly		
General instructions . . . . .	1-2	04-04	- Assembly . . . . .	39-40-41- 42-43-44- 45-46-47- 48-49-50- 51-52-53- 54-55-56- 57	04-04
Safety regulations . . . . .	3-4-5	04-04			
Consumables . . . . .	6	04-04			
<b>10 - ENGINE</b>					
Summary . . . . .	1	04-04	Checks and measure- ments - cylinder block and liners . . . . .	58-59	04-04
General specifications . . . . .	2-3-4	04-04	Checks and measure- ments - crankshaft, bear- ings and flywheel . . . . .	60-61-62- 63	04-04
Fuel system data . . . . .	5-12	04-04	Checks and measure- ments - connecting rods .	64	04-04
Injection pump calibration and engine performance data . . . . .	6-7-8-9- 10-11	04-04	Checks and measure- ments - pistons . . . . .	65-66-67	04-04
Engine block data . . . . .	12	04-04	Checks and measure- ments - camshaft, tappets and valves . . . . .	68-69-70	04-04
Crankshaft data . . . . .	13-14	04-04	Checks and measure- ments - cylinder head . . .	71	04-04
Connecting rod data . . . . .	14	04-04	Re-facing valve seats . . .	72	04-04
Piston data . . . . .	15	04-04	Checks and measure- ments - lubrication system	73-74	04-04
Timing gear data . . . . .	16-17	04-04	Checks and measure- ments - cooling system . .	74-75	04-04
Cylinder head data . . . . .	18	04-04	Replacing valve guides . . .	76-77-78	04-04
Lubrication and cooling system data . . . . .	19	04-04	Replacing injector sleeves and support . . . . .	79-80	04-04
Tightening torques . . . . .	20	04-04	Removal-Installation - crankshaft front seal . . .	81-82	04-04
Tools . . . . .	21-22	04-04	Valve clearance adjust- ment . . . . .	83-84-85	04-04
Cross-sectional views of engine . . . . .	23-24	04-04	Removal-Installation - fuel tank . . . . .	86-87	04-04
Lubrication diagrams . . . . .	25	04-04	Removal-Installation - in- jectors . . . . .	88	04-04
Engine cooling system dia- gram . . . . .	26	04-04			
Fault diagnosis . . . . .	27-28-29- 30	04-04			
Engine Removal - Installa- tion . . . . .	31-32-33- 34-35-36- 37	04-04			
Compression Test . . . . .	38	04-04			

	Page	Date
Removal - Installation Bosch injection pump . . . .	89-90-91-92	04-04
Bosch injection pump - timing . . . . .	93-94	04-04
Bosch injection pump - air bleeding . . . . .	95	04-04
Exhaust pipe. Removal-Installation . . . . .	96	04-04
Removal-Installation - coolant pump . . . . .	97	04-04
Coolant pump overhaul . . .	98	04-04
Removal-Installation - thermostat valve . . . . .	99	04-04
Removal-Installation - radiator . . . . .	100-101	04-04
<b>18 - CLUTCH</b>		
Data . . . . .	1-2	04-04
Tightening torques . . . . .	2	04-04
Tools . . . . .	2-3	04-04
Cross-sectional views . . .	3-4	04-04
Fault diagnosis . . . . .	5	04-04
Removal-Installation - clutch . . . . .	6-7-8-9	04-04
Clutch overhaul . . . . .	10-11-12-13-14	04-04
Checks and measurements - clutch . . . . .	15-16	04-04
Adjustments - clutch disengagement levers . . . . .	16-17	04-04
Adjustments - clutch pedal	18	04-04
PTO clutch lever adjustment . . . . .	19	04-04
Sectional view of PTO clutch servo control . . . . .	20	04-04
Description and operation of PTO servo control . . . . .	21-22	04-04
PTO servo control adjustment . . . . .	23	04-04
PTO engaged switch adjustment . . . . .	24	04-04

## 21 - TRANSMISSIONS

### CHAPTER 1 - Transmission and range gear (16x16)

Data . . . . .	1-2	04-04
Tightening torques . . . . .	2-3	04-04
Tools . . . . .	4-5-6-7	04-04
Cross-sectional views . . .	8-9-10-11	04-04
Description and Operation	12	04-04
Fault diagnosis . . . . .	12-13	04-04
Removal-Installation - Rear transmission - gearbox casing . . . . .	14-15-16-17-18-19	04-04
Disassembly-Assembly - transmission-gearbox casing . . . . .	20-21-22-23-24-25-26-27	04-04
Gearbox driving and driven shafts end float adjustment.	28	04-04
Sealing compound application diagram . . . . .	29	04-04
Gearbox control lever. Removal - Installation . . . . .	30	04-04
Range gear control lever. Removal - Installation . . . . .	31	04-04
Shuttle control lever. Removal - Installation . . . . .	32	04-04

### CHAPTER 2 - Mechanical transmission and splitter

Data . . . . .	1-2	04-04
Tightening torques . . . . .	2	04-04
Tools . . . . .	2	04-04
Cross-sectional views . . .	3-4-5-6	04-04
Description and Operation	7	04-04
Fault diagnosis . . . . .	8	04-04
Splitter device and creeper unit casing, shafts and bearings disassembly . . . . .	9-10-11	04-04

### CHAPTER 3 - Power Shuttle transmission with Dual Command (2 Speed Power Shift) function

Data . . . . .	1-2	04-04
----------------	-----	-------

	Page	Date
Tightening torques .....	3	04-04
Tools .....	4-5-6-7	04-04
Cross-sectional views ...	8-9-10-11-12	04-04
Description and Operation	13	04-04
Fault diagnosis .....	13	04-04
Disassembly-Assembly - transmission-gearbox casing .....	14-15	04-04
Disassembly-Reassembly - Power Shuttle control valve .....	16-17-18	04-04
Disassembly-Assembly - accumulator .....	19	04-04
Gearbox control valve sole- noid valve. Removal - In- stallation .....	20-21	04-04
Disassembly-Assembly - clutch casing .....	22-23-24-25-26	04-04
Fault code decoding .....	27	04-04
Calibrations .....	28-29-30-31-32-33-34-35-36-37-38-39-40-41-42-43-44-45-46	04-04
First start-up procedure ..	47	04-04
Diagnostics .....	48 to 149	04-04
Power Shuttle control unit input/output wiring diagram	150-151	04-04
Description and operation of the control unit .....	152-153-154-155-156	04-04
<b>23 - DRIVE LINES</b>		
Data .....	1	04-04
Tightening torques .....	2	04-04
Tools .....	3-4	04-04
Cross-sectional views ...	5-6-7	04-04
Description and Operation	8-9	04-04
Fault diagnosis .....	9	04-04

	Page	Date
Drive shafts and guard. Disassembly - Assembly .	10-11-12-13	04-04
Removal-Installation - drive gear casing .....	14-15	04-04
Disassembly-Assembly - drive gear casing .....	16-17-18-19	04-04
Fault code decoding .....	20	04-04
Calibrations .....	21-22-23-24-25-26-27-28	04-04
First start-up procedure ..	29	04-04
Diagnostics .....	30 to 67	04-04
Front PTO and 4WD control unit input/output wiring dia- gram .....	68-69	04-04

## 25 - FRONT AXLE MECHANICAL TRANSMISSION

### CHAPTER 1 - Front mechanical transmission

Data .....	1-2	04-04
Tightening torques .....	3-4-5	04-04
Tools .....	6-7-8-9-10	04-04
Gear diagrams .....	11	04-04
Cross-sectional views ...	12-13-17	04-04
Components .....	14-15-16	04-04
Description and Operation	17	04-04
Fault diagnosis .....	18	04-04
Removal-Installation - front axle .....	19-20-21-22-23-24	04-04
Front axle pivot bushing re- placement .....	25	04-04
Front axle steering cylinder	26-27	04-04
Wheel hub and steering knuckle .....	28-29-30	04-04
Front epicyclic reduction gear .....	30-31-32-33	04-04
Front axle bevel drive sup- port and differential .....	34-35-36	04-04

	Page	Date
Bevel drive with electro-hydraulically controlled differential lock .....	37-38-39-40	04-04
Adjustments - bevel drive .....	41-42-43-44	04-04
Mechanical differential lock .....	45-46	04-04
Lead-drive wheel position check .....	47	04-04
Steering sensor replacement .....	48	04-04
Adjustments - steering sensor .....	49	04-04
Bevel drive and differential (with brake) .....	50-51-52-53-54	04-04
Bevel drive with electro-hydraulic differential lock (with brake) .....	55-56-57-58	04-04
Adjustments - bevel drive (with brake) .....	59-60-61-62-63-64-65-66-67-68	04-04
Electro-hydraulic differential lock overhaul .....	69-70	04-04
<b>27 - REAR AXLE MECHANICAL TRANSMISSION</b>		
Data .....	1-2	04-04
Tightening torques .....	3-4-5	04-04
Tools .....	6-7-8-9	04-04
Cross-sectional views ...	10-11	04-04
Description and Operation .....	12-13	04-04
Fault diagnosis .....	13-14	04-04
Disassembly-Assembly - transmission-gearbox casing .....	15-16-17-18-19-20	04-04
Adjustment - differential lock engagement sleeve position .....	21	04-04
Adjustments - bevel drive .....	22-23-24-25-26	04-04

	Page	Date
Removal-Installation - side gear casing .....	27-28-29	04-04
Disassembly-Assembly - drive wheel shaft .....	29-30-31	04-04
Disassembly-Assembly - epicyclic final drive .....	31	04-04

### 31 - POWER TAKE-OFF

#### CHAPTER 1 - Mechanical power take-off

Data .....	1-2-3	04-04
Tools .....	4	04-04
Tightening torques .....	5-6	04-04
Cross-sectional views ...	7-8	04-04
Description and Operation .....	9-10-11	04-04
Fault diagnosis .....	11	04-04
Disassembly - Assembly - power take-off .....	12-13-14-15	04-04

### 33 - BRAKES

Data .....	1-2	04-04
Tightening torques .....	2-3	04-04
Cross-sectional views ...	4-5-6	04-04
Tools .....	6-7	04-04
Description and Operation .....	7	04-04
Fault diagnosis .....	8-9	04-04
Removal-Installation - service brake .....	10-11	04-04
Removal-Installation - service brake pump .....	12-13-14	04-04
Adjustments - service brake pedals travel .....	14-15	04-04
Service brake circuit air bleeding .....	16-17-18	04-04
Removal-Installation - parking brake .....	19-20	04-04
Adjustments - parking handbrake travel .....	20	04-04

## GENERAL INSTRUCTIONS

### IMPORTANT NOTICE

All maintenance and repair work described in this manual must be performed exclusively by CASE IH service technicians, in strict accordance with the instructions given and using any specific tools necessary. Anyone performing the operations described herein without strictly following the instructions is personally responsible for any eventual injury or damage to property.

### BATTERY

Before carrying out any kind of service operation disconnect and isolate the battery negative lead, unless otherwise requested for specific operations (e.g., operations requiring the engine to be running), after which it is necessary to disconnect the above-mentioned lead to complete the work.

### SHIMMING

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated for each shim.

### ROTATING SHAFT SEALS

For correct rotating shaft seal installation, proceed as follows:

- before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes;
- thoroughly clean the shaft and check that the working surface on the shaft is not damaged;
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal;
- coat the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- insert the seal in its seat and press down using a flat punch; do not tap the seal with a hammer or mallet;
- whilst inserting the seal, check that it is perpendicular to the seat; once settled, make sure that it makes contact with the thrust element, if required;
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations.

### “O-RING” SEALS

Lubricate the O-RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

### SEALING COMPOUNDS

Apply one of the following sealing compounds on the mating surfaces marked with an X: RTV SILMATE, RHO-DORSIL CAF 1 or LOCTITE PLASTIC GASKET.

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a wire brush;
- thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, petrol or a water and soda solution.

### BEARINGS

When installing bearings it is advised to:

- heat the bearings to 178 to 194 °F (80 to 90 °C) before fitting on the shafts;
- allow the bearings to cool before installing them from the outside.

## SPRING PINS

When fitting split socket elastic pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral spring pins do not require special positioning.

## SPARE PARTS

Use genuine parts only.

Only genuine spare parts guarantee the same quality, duration and safety as they are the same parts that are assembled during production.

Only **genuine parts** can offer this guarantee.

When ordering spare parts, always provide the following information:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found in the "Microfiches" or the "Spare Parts Catalogue", used for order processing.

## TOOLS

The tools that CASE IH propose and illustrate in this manual are:

- specifically researched and designed for use with CASE IH vehicles;
- essential for reliable repair operations;
- accurately built and rigorously tested so as to offer efficient and long-lasting operation.

By using these tools, repair personnel will benefit from:

- operating in optimal technical conditions;
- obtaining the best results;
- saving time and effort;
- working in safe conditions.

## IMPORTANT NOTES

Wear limit values indicated for certain parts are recommended, but not binding. The terms "front", "rear", "right-hand" and "left-hand" (when referred to different parts) are intended as seen from the driving position with the vehicle in the normal direction of movement.

## MOVING THE TRACTOR WITH THE BATTERY REMOVED

External power supply cables should only be connected to the respective positive and negative cable terminals, using efficient clamps that guarantee adequate and secure contact.

Disconnect all services (lights, windshield wipers, etc.) before starting the vehicle.

If the vehicle electrical system requires checking, carry out operations with the power supply connected; once checking is completed, disconnect all services and switch off the power supply before disconnecting the cables.



## SAFETY REGULATIONS


### PAY ATTENTION TO THIS SYMBOL

*This warning symbol points out important messages concerning your safety.*

*Carefully read the following safety regulations and observe advised precautions in order to avoid potential hazards and safeguard your health and safety. In this manual the symbol is accompanied by the following key-words:*

**CAUTION** - Warnings concerning unsuitable repair operations that may jeopardise the safety of Service personnel.

**DANGER** - Specific warnings concerning potential hazards for operator safety or for other persons directly or indirectly involved.



1

### ACCIDENT PREVENTION

Most accidents or injuries that occur in workshops are the result of non-observance of simple and fundamental safety regulations. For this reason, IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED by foreseeing possible causes and consequently acting with the necessary caution and care. Accidents may occur with all types of vehicle, regardless of how well it was designed and built.

A careful and judicious service technician is the best guarantee against accidents.

Precise observance of the most basic safety rule is normally sufficient to avoid many serious accidents.

**DANGER.** Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

## SAFETY REGULATIONS

### GENERAL GUIDELINES

- Carefully follow specified repair and maintenance procedures.
- Do not wear rings, wristwatches, jewellery, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips that may remain entangled in moving parts. It is advised to wear approved safety clothing, e.g.: non-slip footwear, gloves, safety goggles, helmets, etc.
- Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a trained technician who is assisting with the operation in question.
- Do not operate the vehicle or use any of the implements from different positions, other than the driver's seat.

- Do not carry out operations on the vehicle with the engine running, unless specifically indicated.
- Stop the engine and check that the hydraulic circuits are pressure-free before removing caps, covers, valves, etc.
- All repair and maintenance operations must be carried out using extreme care and attention.
- Service steps and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- Disconnect the batteries and label all controls to indicate that the vehicle is being serviced. Any parts that are to be raised must be locked in position.
- Do not check or fill fuel tanks, accumulator batteries, nor use starting liquid when smoking or near naked flames, as these fluids are inflammable.
- Brakes are inoperative when manually released for repair or maintenance purposes. Use blocks or similar devices to control the machine in these conditions.
- The fuel nozzle should always be in contact with the filling aperture. Maintain this position until filling operations are completed in order to avoid possible sparks caused by the accumulation of static electricity.
- Only use specified towing points for towing the tractor. Connect parts carefully. Make sure that all pins and/or locks are secured in position before applying traction. Never remain near the towing bars, cables or chains that are operating under load.
- Transport vehicles that cannot be driven using a trailer or a low-loading platform trolley, if available.

- When loading or unloading the vehicle from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels. Firmly secure the tractor to the truck or trailer and lock the wheels in the position used by the carrier.
- Electric heaters, battery-chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- Take extra care if bystanders are present.
- Never pour petrol or diesel oil into open, wide or low containers.
- Never use petrol, diesel oil or other inflammable liquids as cleaning agents. Use non-inflammable, non toxic commercially available solvents.
- Wear safety goggles with side guards when cleaning parts with compressed air.
- Limit the air pressure to a maximum of 30.45 psi (2.1 bar), according to local regulations.
- Do not run the engine in confined spaces without suitable ventilation.
- Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- Never use naked flames for lighting when working on the machine or checking for "leaks".
- All movements must be carried out carefully when working under, on or near the vehicle. Wear protective equipment: helmets, goggles and special footwear.
- When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- If operating outside the workshop, position the vehicle on a flat surface and lock in position. If working on a slope, lock the vehicle in position. Move to a flat area as soon as is safely possible.
- Damaged or bent chains or cables are unreliable. Do not use them for lifting or towing. Always use suitable protective gloves when handling chains or cables.
- Chains should always be safely secured. Make sure that the hitch-up point is capable of sustaining the load in question. Keep the area near the hitch-up point, chains or cables free of all bystanders.
- Maintenance and repair operations must be carried out in a CLEAN and DRY area. Eliminate any water or oil spillage immediately.
- Do not create piles of oil or grease-soaked rags as they represent a serious fire hazard. Always place them into a metal container. Before starting the tractor or its attachments, check, adjust and block the operator's seat. Also check that there are no persons within the tractor or implement range of action.
- Do not keep into your pockets any object which might fall unobserved into the tractor's inner compartments.
- In the presence of protruding metal parts, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles. NEVER LOOK DIRECTLY AT THE WELDING ARC WITHOUT SUITABLE EYE PROTECTION.
- Metal cables tend to fray with repeated use. Always use suitable protective devices (gloves, goggles, etc.) when handling cables.
- Handle all parts carefully. Do not put your hands or fingers between moving parts. Always wear suitable safety clothing – safety goggles, gloves and shoes.

### START UP

- Never run the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- Never bring your head, body, arms, legs, feet, hands, fingers near fans or rotating belts.

### ENGINE

- Always loosen the radiator cap slowly before removing it to allow any remaining pressure in the system to be discharged. Filling up with coolant should only be carried out with the engine stopped or idling (if hot).
- Never fill up with fuel when the engine is running, especially if hot, in order to prevent the outbreak of fire as a result of fuel spillage.
- Never check or adjust fan belt tension when the engine is running. Never adjust the fuel injection pump when the vehicle is moving.

- Never lubricate the vehicle when the engine is running.

### **ELECTRICAL SYSTEMS**

- If it is necessary to use auxiliary batteries, remember that both ends of the cables must be connected as follows: (+) with (+) and (-) with (-). Avoid short-circuiting the terminals. **GAS RELEASED FROM BATTERIES IS HIGHLY INFLAMMABLE.** During charging, leave the battery compartment uncovered to improve ventilation. Never check the battery charge using "jumpers" (metal objects placed on the terminals). Avoid sparks or flames near the battery zone. Do no smoke to prevent explosion hazards.
- Before servicing operations, check for fuel or current leaks. Eliminate any eventual leaks before proceeding with work.
- Never charge batteries in confined spaces. Make sure that there is adequate ventilation in order to prevent accidental explosion hazards as a result of the accumulation of gases released during charging operations.
- Always disconnect the batteries before performing any kind of servicing on the electrical system.

### **HYDRAULIC SYSTEMS**

- A liquid leaking from a tiny hole may be almost invisible but, at the same time, be powerful enough to penetrate the skin. Therefore, **NEVER USE HANDS TO CHECK FOR LEAKS.** Use a piece of cardboard or wood for this purpose. If any liquid penetrates skin tissue, call for medical aid immediately. Failure to treat this condition with correct medical procedure may result in serious infection or dermatosis.
- In order to check the pressure in the system use suitable instruments.

### **WHEELS AND TYRES**

- Check that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check for possible damage to the rims and tyres.
- Stand away from (at the side of) the tyre when checking inflation pressure.
- Only check pressure when the tractor is unloaded and the tyres are cold, to avoid incorrect readings as a result of over-pressure. Do not reuse parts of recovered wheels as improper welding, brazing or heating may weaken the wheel and make it fail.
- Never cut or weld a rim mounted with an inflated tyre.
- To remove the wheels, lock both the front and rear vehicle wheels. After having raised the vehicle, position supports underneath, according to regulations in force.
- Deflate the tyre before removing any object caught in the tyre tread.
- Never inflate tyres using inflammable gases; as this may result in explosions and injury to bystanders.

### **REMOVAL AND INSTALLATION**

- Lift and handle all heavy parts using suitable hoisting equipment. Ensure that parts are supported by appropriate slings and hooks. Use lifting eyes provided to this purpose. Extra care should be taken if persons are present near the load to be lifted.
- Handle all parts carefully. Do not put your hands or fingers between parts. Wear suitable safety clothing, safety goggles, gloves and footwear.
- Avoid twisting chains or metal cables. Always wear safety gloves when handling cables or chains.

**CONSUMABLES**

COMPONENT TO BE FILLED OR TOPPED UP	QUANTITY US gal. (litres)	RECOMMENDED CASE IH PRODUCTS	CASE IH SPECIFICATIONS	INTERNATIONAL SPECIFICATIONS
Cooling system:		Water and <b>AKCELA PREMIUM ANTI-FREEZE</b>	MS 1710	-
without cab . . . . .	2.64 (10)			
with cab . . . . .	3.17 (12)			
Windscreen washer reservoir . . . . .	0.52 (2)	Water and liquid detergent	-	-
Fuel tank:		Decanted and filtered diesel fuel	-	-
- JX1060V, JX1070V, JX1070N, . . . . .	15.05 (57)			
- JX1075V, JX1075N) .	14.52 (55)			
Engine sump:		Oil <b>AKCELA N. 1 ENGINE OIL</b>	MS 1121	API CH-4 ACEA E5 SAE 15W 40
without filter: . . . . .	1.76 (6.7)			
with filter: . . . . .	1.98 (7.5)			
Brake circuit . . . . .	0.13 (0.5)	Oil <b>AKCELA LHM FLUID</b>	-	ISO 7308
With front brakes . . . . .	0.18 (0.7)			
Front axle:		Oil <b>AKCELA GEAR 135H EP</b>	MS 1316	MIL-L-2105D SAE 80W-90
- axle housing . . . . .	1.05 (4.0)			
- final drives (each): . . . . .	0.15 (0.6)			
Rear transmission (bevel drive, final drives and brakes), gearbox, hydraulic lift, PTO and hydraulic steering: . . . . .	11.62 (44)	Oil <b>AKCELA NEXPLORE</b>	MAT 3525	-
Grease fittings . . . . .	-	Grease <b>AKCELA MULTIPURPOSE GREASE</b>	251H EP	NLGI 2

## SECTION 10 - ENGINE

### Chapter 1 - Engine

#### CONTENTS

Section	Description	Page
<b>10 000</b>	General specifications .....	2
	Main data .....	5
	Torque settings .....	20
	Tools .....	21
	Sections .....	23
	Lubrication and cooling system diagrams .....	25
	Troubleshooting .....	27
<b>10 001 10</b>	Engine. Removal - Installation .....	31
<b>10 001 30</b>	Compression. test .....	38
<b>10 001 54</b>	Engine. Disassembly - Assembly .....	39
<b>10 101 53</b>	Valve guides. Replacement .....	76
<b>10 101 60</b>	Injector sleeve. Replacement .....	79
<b>10 102 70</b>	Front engine oil seal. Removal - Installation .....	81
<b>10 106 12</b>	Valve-rocker arm clearance adjustment .....	83
<b>10 216 10</b>	Fuel tank. Removal - Installation .....	86
<b>10 218 30</b>	Engine injector. Removal - Installation .....	88
<b>10 246 14</b>	Bosch injection pump. Removal, installation, timing check and air bleeding .....	89
<b>10 254 44</b>	Exhaust pipe. Removal - Installation .....	96
<b>10 402 11</b>	Coolant pump. Removal and installation with radiator removed .....	97
<b>10 402 28</b>	Coolant pump. Overhaul .....	98
<b>10 402 30</b>	Thermostat valve. Removal - Installation .....	99
<b>10 406 10</b>	Radiator. Removal - Installation .....	100

GENERAL SPECIFICATIONS	
Engine, technical type:	
- Mod. JX1060V - type 8035.05C.925/929 (BOSCH pump) .....	See data on page 6-7
- Mod. JX1070V and JX1070N - type 8035.25R.925/929 (BOSCH pump) ..	See data on page 8-9
- Mod. JX1075V and JX1075N - type 8035.25.925/929 (BOSCH pump) ...	See data on page 10-11
Cycle .....	diesel, 4-stroke
Fuel injection .....	direct
Number of cylinders in line .....	3
Cylinder liners .....	dry force-fitted in cylinder block
Piston diameter	
- Mod. JX1060V .....	4.0944 in. (104 mm)
- Mod. JX1070V and JX1070N .....	4.0944 in. (104 mm)
- Mod. JX1075V and JX1075N .....	4.0944 in. (104 mm)
Piston stroke .....	4.5275 in. (115 mm)
Total displacement:	
- Mod. JX1060V .....	178.84 in <sup>3</sup> (2931 cm <sup>3</sup> )
- Mod. JX1070V and JX1070N .....	178.84 in <sup>3</sup> (2931 cm <sup>3</sup> )
- Mod. JX1075V and JX1075N .....	178.84 in <sup>3</sup> (2931 cm <sup>3</sup> )
Compression ratio for Mod. JX1060V, JX1070V and JX1070N .....	17:1 normally aspirated
Compression ratio for Mod. JX1075V and JX1075N .....	16.5:1 turbocharged
Maximum power:	
- Mod. JX1060V .....	43.5 kW (59 Hp)
- Mod. JX1070V and JX1070N .....	53 kW (72 Hp)
- Mod. JX1075V and JX1075N .....	55.5 kW (76 Hp)
Maximum power speed .....	2300 rpm
Maximum torque speed for Mod. JX1060V .....	1400 rev/min
Maximum torque speed for Mod. JX1070V and JX1070N .....	1400 rev/min
Maximum torque speed for Mod. JX1075V and JX1075N .....	1400 rev/min
Number of main bearings .....	4
Sump .....	structural, cast iron

(continued)

(cont)

GENERAL SPECIFICATIONS	
<b>Lubrication</b> .....	forced, with gear pump
Pump drive .....	camshaft
Engine speed/oil pump speed ratio .....	2:1
Oil cleaning .....	mesh filter on oil intake and filtering cartridge on delivery line
Normal oil pressure with motor warmed-up and running at maximum speed:	
For mod. JX1060V, .....	0.19 to 0.26 psi (2.9 to 3.9 bar)
For mod. JX1070V, JX1070N, JX1075V and JX1075N (start of action) .....	$\geq 0.13$ psi ( $\geq 2$ bar)
Pressure relief valve .....	incorporated in oil pump housing
Valve initial opening pressure .....	0.24 psi (3.5 bar)
For further lubrication technical data .....	see page 19
<b>Cooling</b> .....	coolant circulation
Radiator on mod. JX1060V, JX1070V/N .....	3 lines of vertical pipes with copper fins
Radiator on mod. JX1075V/N .....	4 lines of vertical copper pipes
Fan, attached to coolant pump pulley .....	intake, 6-blade in sheet-metal
Coolant pump .....	centrifugal vane-type
Engine speed/coolant pump speed ratio .....	1:1.25
Temperature control .....	thermostat
Coolant thermometer .....	coloured scale divided into 3 sections
Temperature ranges corresponding to each section:	
- initial white section .....	86° to 149 °F (30° to 65 °C)
- middle green section (normal working conditions) .....	149° to 221 °F (65° to 105 °C)
- final red section .....	221° to 239 °F (105° to 115 °C)
For further cooling system technical data .....	see page 19
<b>Rev counter/hourmeter</b> .....	incorporated in control panel
Control .....	from gear on camshaft
Hour counter calibrated for engine speed of .....	1800 rpm

(continued)

Click on the image link below for the full version of the service manual

