

The CASE logo is displayed in white, bold, italicized capital letters. It is positioned on a black trapezoidal background that tapers to the left. A horizontal orange bar is located directly beneath the letters.

REPAIR MANUAL
SKID STEER

430
440
440CT
SERIES 3

87634767 NA

Issued 01Jan08

REPAIR MANUAL
SKID STEER / TRACK LOADERS

**430
440
440CT
SERIES 3**

87634767 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

REPAIR MANUAL
SKID STEER / TRACK LOADERS

**430
440
440CT
SERIES 3**

87634767 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

REPAIR MANUAL
SKID STEER / TRACK LOADERS

**430
440
440CT
SERIES 3**

87634767 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

REPAIR MANUAL
SKID STEER / TRACK LOADERS

**430
440
440CT
SERIES 3**

87634767 NA

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

430/440 SKID STEER AND 440CT COMPACT TRACK LOADER

Repair Manual Mechanical and Pilot Control Machines (Tier 3 and Cab Up-Grade Machines)

Bur 87634767

Table of Contents

Description	Section Number	Publication Form Number
General		
	Tab 1	
Section Index - General		6-79151
Fluids and Lubricants	1001	6-79031
Fluids and Lubricants Tier 3 Engines	1001	5-9520
Standard Torque Specifications	1002	7-52931
Metric Conversion Chart	1003	7-52950
Engines		
	Tab 2	
Section Index - Engines		6-79161
Engine and Radiator Removal and Installation	2000	6-79290
Engine and Radiator Removal and Installation (430 Tier 3 Engine)	2000	5-9540
Engine and Radiator Removal and Installation (440/440CT Tier 3 Engine)	2000	5-9550
For Engine Repair - See Engine Service Manual		6-74500
For 430 Tier 3 Engine Repair - See Tier 3 Engine Repair Manual		87693888
For 440/440CT Tier 3 Engine Repair - See Tier 3 Engine Repair Manual		87630273
Fuel Systems		
	Tab 3	
Section Index - Fuel Systems		6-79171
For Fuel System Repair - See the Engine Service Manual		6-74500
For 430 Tier 3 Fuel System Repair - See Tier 3 Engine Repair Manual		87693888
For 440/440CT Tier 3 Fuel System Repair - See Tier 3 Engine Repair Manual		87630273
Electrical		
	Tab 4	
Section Index - Electrical		6-79182
Electrical System Specifications, Troubleshooting, and Schematics (Mechanical and Pilot Control Machines)	4001	6-79371
Electrical System Specifications, Troubleshooting, and Schematics (Tier 3 and Cab Up-Grade Machines)	4001	5-9600
Battery	4005	7-51310
Starter and Starter Solenoid	4006	7-53091

430/440 SKID STEER AND 440CT COMPACT TRACK LOADER

Repair Manual Mechanical and Pilot Control Machines (Tier 3 and Cab Up-Grade Machines)

Bur 87634767

Table of Contents (Continued)

Description	Section Number	Publication Form Number
Tracks Tab 5		
Section Index - Tracks		5-2630
Tracks	5001	5-2610
Drive Sprocket, Idler Wheels, and Rollers	5002	5-2620
Power Train Tab 6		
Section Index - Power Train		6-79192
Hydrostatic System "How it Works" (ISO- Pattern and H-Pattern Pilot Control Machines)	6000	5-4930
Hydrostatic System Troubleshooting	6001	6-79331
Hydrostatic System Troubleshooting (Machines Equipped with Pilot Controls)	6001	5-4910
Removal and Installation of Hydrostatic Components (Mechanical and Pilot Control Machines)	6002	6-79322
Drive Coupling	6003	6-79230
Drive Coupling Tier 3 Engines	6003	5-9530
Piston Pump	6004	6-49580
Piston Pump (Machines Equipped with Pilot Controls)	6004	5-4921
Drive Motors Single Speed	6005	6-79000
Drive Motors Two Speed	6005	6-79010
Sprocket, Chains, and Axle Assemblies	6007	6-79300
Wheels and Tires	6011	6-79310
Brakes Tab 7		
Section Index - Brakes		6-79200
Removal and Installation of Park Brake Components	7002	6-79441
Hydraulics Tab 8		
Section Index - Hydraulics		6-79212
Hydraulic System Troubleshooting and Schematics (Mechanical and Pilot Control Machines)	8001	6-79342
Cleaning the Hydraulic System and Hydrostatic System	8002	6-45290
Removal and Installation of Hydraulic Components	8003	6-79431
Gear Pump (Equipment and High Flow)	8004	6-79350
Loader Control Valve	8005	5-2640
Cylinders	8006	6-79360
Flat Faced Couplers	8007	7-54740
Accumulator for Ride Control	8013	6-45550

430/440 SKID STEER AND 440CT COMPACT TRACK LOADER

Repair Manual Mechanical and Pilot Control Machines (Tier 3 and Cab Up-Grade Machines)

Bur 87634767

Table of Contents (Continued)

Description	Section Number	Publication Form Number
Mounted Equipment		
		Tab 9
Section Index - Mounted Equipment		6-79221
Pedals and Levers	9001	6-79421
Pedals and Levers (Cab Up-Grade Machines)	9001	5-9560
Loader	9002	6-79390
Attachment Coupler	9003	6-79400
ROPS Canopy, Seat, Seat Belts, and Operators Compartment	9004	6-79410
ROPS Canopy, Seat, Seat Belts, and Operators Compartment (Cab Up-Grade Machines)	9004	5-9460
Heater	9006	6-79450
Air Conditioning Troubleshooting for Systems with R-134A Refrigerant	9011	6-79460
Air Conditioning Troubleshooting for Systems with R-134A Refrigerant (Cab Up-Grade Machines)	9011	5-9480
Air Conditioner System Gauges and Testing for Systems with R-134A Refrigerant	9012	6-79470
Air Conditioner System Gauges and Testing for Systems with R-134A Refrigerant (Cab Up-Grade Machines)	9012	5-9490
Air Conditioner System Service for Systems with R-134A Refrigerant Refrigerant Recovery, Compressor Removal and System Evacuation and Recharging	9013	6-79480
Air Conditioner System Service for Systems with R-134A Refrigerant Refrigerant Recovery, Compressor Removal and System Evacuation and Recharging (Cab Up-Grade Machines)	9013	5-9500
Air Conditioner Component Service for Systems with R-134A Refrigerant	9014	6-79490
Air Conditioner Component Service for Systems with R-134A Refrigerant (Cab Up-Grade Machines)	9014	5-9510
Schematic Set		
Hydraulic and Electrical Schematic Foldout	In Rear Pocket	5-5351
Hydraulic and Electrical Schematic Foldout (Tier 3 Cab Up-Grade and Pilot Control Machines)	In Rear Pocket	5-9620

430/440 SKID STEER AND 440CT COMPACT TRACK LOADER

**Repair Manual
Mechanical and Pilot Control Machines
(Tier 3 and Cab Up-Grade Machines)**

Bur 87634767

Table of Contents (Continued)

NOTES

SECTION INDEX

GENERAL

Section Title	Section Number
Fluids and Lubricants	1001
Fluids and Lubricants Tier 3 Engines	1001
Standard Torque Specifications	1002
Metric Conversion Chart	1003

Click on the image link below for the full version of the service manual



Section 1001

FLUIDS AND LUBRICANTS

TABLE OF CONTENTS

CAPACITIES AND LUBRICANTS	3
ENVIRONMENT	3
ENGINE LUBRICATION	4
Engine Oil Selection	4
Oil Viscosity/Temperature Ranges	4
DIESEL FUEL SYSTEM	5
Fuel Storage	5
Specifications for Acceptable No. 2 Diesel Fuel	5

CAPACITIES AND LUBRICANTS

FUEL TANK

Capacity 83.3 litres (22 U.S. gallons)
 Specifications See diesel fuel specifications on page 5

COOLING SYSTEM

Capacity 17 litres (17.9 quarts)
 Recovery bottle capacity 2 litres (2.1 quarts)
 Specifications 50% water and 50% ethylene glycol

HYDRAULIC SYSTEM

Capacity - Total System 50.2 litres (13.3 gallons)
 Capacity - Reservoir 32.4 litres (7.1 gallons)
 Specifications Case Akcela No. 1 Engine Oil SAE 10W30

CHAIN COMPARTMENTS

Capacity - Each Side 5.7 litres (6.0 quarts)
 Specifications Case Akcela No. 1 Engine Oil, SAE 10W30

FINAL DRIVE (CT MODELS)

Capacity - Each Side 0.55 L (0.58 quarts)
 Specifications CASE AKCELA GEAR LUBE SSL 75W-90 (Synthetic)

BATTERY

Quantity As required
 Specifications Distilled water

GREASE FITTINGS

Quantity As required
 Attachments (If equipped) Quantity as required
 Specifications Case molydisulfide grease

ENGINE CRANKCASE OIL (410/420 and 420CT MACHINES)

Capacity - with filter change 8.7 litres (9.2 quarts)
 Capacity - without filter change 8.5 litres (9 quarts)
 Specifications Case Akcela No. 1 Engine Oil SAE 10W-30 (API service CH-4)
 (See Oil Viscosity/Temperature Ranges Chart on page 4)

ENGINE CRANKCASE OIL (430/440 and 440CT MACHINES)

Capacity - with filter change 12 litres (12.7 quarts)
 Specifications Case Akcela No. 1 Engine Oil SAE 10W-30 (API service CH-4)
 (See Oil Viscosity/Temperature Ranges Chart on page 4)

ENVIRONMENT

Before you service this machine and dispose of oil, fluids and lubricants, always remember the environment. Do not put oil or fluids into the ground or into containers that can leak. Check with your local environmental, recycling center or your Case dealer for correct disposal information.

ENGINE LUBRICATION


Engine Oil Selection

Case Akcela No. 1 Engine Oil is recommended for use in your Case Engine. Case Akcela Engine Oil will lubricate your engine correctly under all operating conditions.

See the chart below for recommended viscosity at ambient temperature ranges.

NOTE: Do not put Performance Additives or other oil additive products in the engine crankcase. The oil change intervals given in the operating manual are according to tests with Case lubricants.

Oil Viscosity/Temperature Ranges



Indicates use of an engine oil heater or a jacket water heater is required.

BS99N019

DIESEL FUEL SYSTEM

Use No. 2 diesel fuel in the engine of this machine. The use of other fuels can cause the loss of engine power and high fuel consumption.

In very cold temperatures, a mixture of No. 1 and No. 2 diesel fuels is temporarily permitted. See the following:

NOTE: See your fuel dealer for winter fuel requirements in your area. If the temperature of the fuel lowers below the cloud point (wax appearance point), wax crystals in the fuel will restrict the fuel filter and cause the engine to lose power or not start.

The diesel fuel used in this machine must meet the specifications below, "Specifications for Acceptable No. 2 Diesel Fuel" or Specification D975-81 of the American Society for Testing and Materials.

Fuel Storage

If you keep fuel in storage for a period of time, you can get foreign material or water in the fuel storage tank. Many engine problems are caused by water in the fuel.

Keep the fuel storage tank outside and keep the fuel as cool as possible. Remove water from the storage container at regular periods of time.

Fill the fuel tank at the end of the daily operating period to prevent condensation in the fuel tank.

Specifications for Acceptable No. 2 Diesel Fuel

API Gravity, Minimum	34
Flash Point, Minimum	60° C (140° F)
Cloud Point (wax appearance point), Maximum	-20° C (-5° F)
Pour Point, Maximum	-26° C (-15° F)
Distillation Temperature, 90% Point	282 to 338° C (540 to 640° F)
Viscosity, at 38° C (100° F)	
Centistokes	2.0 to 4.3
Saybolt Seconds Universal	32 to 40
Cetane Number, Minimum	43 (45 to 55 for winter or high altitudes)
Water and Sediment, by Volume, Maximum	0.5 of 1%
Sulphur, by Weight, Maximum	0.5 of 1%
Copper Strip Corrosion, Maximum	No. 2
Ash, by Weight, Maximum	0.1 of 1%

NOTES

Section 1001

FLUIDS AND LUBRICANTS

Tier 3 Engines