NOTE: *Engine repair information is not contained within this tractor Repair Manual. For engine repair, refer to publication number 87515687 for the 8.3 & 9.0L 6 Cylinder, 24 Valve CNH Engine with High Pressure Common Rail Fuel System.*

BOOK 1 - General, Electrical, Engine, Steering - 87525613

STANDARD TORQUE SPECIFICATIONS ..... SECTION 1000
- TORQUE SPECIFICATIONS - METRIC HARDWARE 1000-4
- TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 1000-5
- TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 1000-6

SAFETY, GENERAL INFORMATION, MAINTENANCE SCHEDULE ..... SECTION 1001
- SAFETY 1001-3
- GENERAL INFORMATION 1001-5
- LUBRICATION/MAINTENANCE CHART 1001-6
- SYSTEM CAPACITIES 1001-7

COOLING SYSTEM MODULE REMOVAL AND INSTALLATION ..... SECTION 2001
- COOLING SYSTEM MODULE REMOVAL 2001-3
- COOLING SYSTEM MODULE INSTALLATION 2001-7

ENGINE REMOVAL AND INSTALLATION ..... SECTION 2002
- SPECIAL TORQUES 2002-3
- ENGINE REMOVAL 2002-4
- ENGINE INSTALLATION 2002-21

VISCOUS FAN DRIVE TEST ..... SECTION 2003
- REQUIRED TOOLS 2003-3
- DIAGNOSTIC PROCEDURE 2003-4
- FAN SPEED TEST 2003-7

FUEL TANK / FUEL SENDER REMOVAL AND INSTALLATION ..... SECTION 3001
- SPECIAL TORQUES 3001-3
- FUEL TANK REMOVAL AND INSTALLATION 3001-3
- FUEL LEVEL SENDER REMOVAL AND INSTALLATION 3001-10

ELECTRICAL SCHEMATIC POSTER - Prior to P.I.N. Z6RZ04001 87389708

ELECTRICAL SCHEMATIC POSTER - P.I.N. Z6RZ04001 and After 87588600

ELECTRICAL SCHEMATIC POSTER - P.I.N. Z7RZ01521 and After 87624272

ELECTRICAL SYSTEM - HOW IT WORKS AND TROUBLESHOOTING ..... SECTION 4001
- SPECIAL TOOLS 4001-4
- FUSES AND RELAY IDENTIFICATION 4001-5
  - Cab Fuses/Relay Location 4001-5
  - Engine Compartment Fuse/Relay Identification (Power Distribution Box) 4001-5
  - Fuse Identification 4001-6
  - Relays 4001-7
- INSTRUMENTATION AND CONTROLS 4001-8
- CONNECTOR AND COMPONENT LOCATIONS 4001-12
- ELECTRICAL CONNECTORS 4001-35
- ELECTRICAL SYSTEMS SCHEMATICS AND DIAGNOSTICS 4001-142
  - Power Distribution System Circuit Operation 4001-142
  - Power Distribution Circuit Troubleshooting 4001-142
  - Power Distribution Schematic 4001-142

POWER DISTRIBUTION SYMPTOM CHART 4001-143
Diagnostic Tests 4001-144
AUDIO SYSTEM 4001-146
Audio System Circuit Operation 4001-146
Audio System Circuit Troubleshooting 4001-146
Audio System Symptom Chart 4001-146
Audio System Diagnostic Tests 4001-148
CHARGING SYSTEM 4001-152
Charging System Circuit Operation 4001-152
Charging System Circuit Troubleshooting 4001-152
Charging System Symptom Chart 4001-153
Charging System Diagnostic Tests 4001-154
EXTERIOR LIGHTING SYSTEM 4001-158
Exterior Lighting System Circuit Operation 4001-158
Exterior Lighting System Circuit Troubleshooting 4001-158
Exterior Lighting System Symptom Chart 4001-159
Exterior Lighting System Diagnostic Tests 4001-159
INSTRUMENTATION AND WARNING SYSTEM 4001-164
Instrumentation and Warning System Circuit Troubleshooting 4001-164
Instrumentation and Warning System Symptom Chart 4001-164
Instrumentation and Warning System Diagnostic Tests 4001-165
INTERIOR LIGHTING AND HORN SYSTEM 4001-168
Interior Lighting and Horn System Circuit Operation 4001-168
Interior Lighting and Horn System Circuit Troubleshooting 4001-168
Interior Lighting and Horn System Symptom Chart 4001-169
Interior Lighting and Horn System Diagnostic Tests 4001-169
POWER MIRROR SYSTEM 4001-173
Power Mirror Circuit Operation 4001-173
Power Mirror Circuit Troubleshooting 4001-173
Power Mirror System Symptom Chart 4001-174
Power Mirror System Diagnostic Tests 4001-176
POWER SEAT SYSTEM 4001-185
Power Seat System Circuit Operation 4001-185
Power Seat System Circuit Troubleshooting 4001-185
Power Seat System Symptom Chart 4001-186
Power Seat System Diagnostic Tests 4001-187
STARTING SYSTEM 4001-191
Starting System Circuit Operation 4001-191
Starter Motor Circuit Troubleshooting 4001-191
Starting System Symptom Chart 4001-191
Starting System Diagnostic Tests 4001-193
WIPER/WASHER SYSTEM 4001-198
Wiper/Washer System Circuit Operation 4001-198
Wiper/Washer System Circuit Troubleshooting 4001-198
Wiper/Washer System Symptom Chart 4001-199
Wiper/Washer System Diagnostic Tests 4001-200

STEERING COLUMN AND STEERING HAND PUMP ..... SECTION 5001
SPECIAL TOOLS 5001-2
SPECIAL TORQUES 5001-3
STEERING COLUMN AND STEERING HAND PUMP 5001-3
REMOVAL 5001-3
STEERING HAND PUMP SERVICE 5001-7
STEERING COLUMN ASSEMBLY 5001-9
INSTALLATION 5001-10

BOOK 1A - Electrical (continued) - 87611218

ELECTRICAL SYSTEM - HOW IT WORKS AND TROUBLESHOOTING, P.I.N. Z6RZ04001 AND AFTER
SPECIAL TOOLS 4002-4
FUSES AND RELAY IDENTIFICATION 4002-5
Cab Fuses/Relay Location 4002-5
Engine Compartment Fuse/Relay Identification (Power Distribution Box) 4002-5
Fuse Identification 4002-6
Relays 4002-7
INSTRUMENTATION AND CONTROLS 4002-8
CONNECTOR AND COMPONENT LOCATIONS 4002-12
ELECTRICAL CONNECTORS 4002-34
ELECTRICAL SYSTEMS SCHEMATICS AND DIAGNOSTICS 4002-141
Power Distribution System Circuit Operation 4002-141
Power Distribution Circuit Troubleshooting 4002-141
Power Distribution Schematic 4002-141
POWER DISTRIBUTION SYMPTOM CHART 4002-142
Diagnostic Tests 4002-143
AUDIO SYSTEM 4002-145
Audio System Circuit Operation 4002-145
Audio System Circuit Troubleshooting 4002-145
Audio System Symptom Chart 4002-145
Audio System Diagnostic Tests 4002-147
CHARGING SYSTEM 4002-151
Charging System Circuit Operation 4002-151
Charging System Circuit Troubleshooting 4002-151
Charging System Symptom Chart 4002-152
Charging System Diagnostic Tests 4002-153
EXTERIOR LIGHTING SYSTEM 4002-157
Exterior Lighting System Circuit Operation 4002-157
Exterior Lighting System Circuit Troubleshooting 4002-157
Exterior Lighting System Symptom Chart 4002-158
Exterior Lighting System Diagnostic Tests 4002-158
INSTRUMENTATION AND WARNING SYSTEM 4002-163
Instrumentation and Warning System Circuit Troubleshooting 4002-163
Instrumentation and Warning System Symptom Chart 4002-163
Instrumentation and Warning System Diagnostic Tests 4002-164
INTERIOR LIGHTING AND HORN SYSTEM 4002-167
Interior Lighting and Horn System Circuit Operation 4002-167
Interior Lighting and Horn System Circuit Troubleshooting 4002-167
Interior Lighting and Horn System Symptom Chart 4002-168
Interior Lighting and Horn System Diagnostic Tests 4002-168
POWER MIRROR SYSTEM 4002-172
Power Mirror Circuit Operation 4002-172
Power Mirror Circuit Troubleshooting 4002-172
Power Mirror System Symptom Chart 4002-173
Power Mirror System Diagnostic Tests 4002-175
POWER SEAT SYSTEM 4002-184
Power Seat System Circuit Operation 4002-184
Power Seat System Circuit Troubleshooting 4002-184
Power Seat System Symptom Chart 4002-185
Power Seat System Diagnostic Tests 4002-186

STARTING SYSTEM 4002-190
Starting System Circuit Operation 4002-190
Starter Motor Circuit Troubleshooting 4002-190
Starting System Symptom Chart 4002-190
Starting System Diagnostic Tests 4002-192
WIPER/WASHER SYSTEM 4002-197
Wiper/Washer System Circuit Operation 4002-197
Wiper/Washer System Circuit Troubleshooting 4002-197
Wiper/Washer System Symptom Chart 4002-198
Wiper/Washer System Diagnostic Tests 4002-199

BOOK 1B - Electrical (Continued) - 87678524

ELECTRICAL SCHEMATIC POSTER - P.I.N. Z7RZ01521 and After 87624272

ELECTRICAL SYSTEM - HOW IT WORKS AND TROUBLESHOOTING,
P.I.N. Z7RZ01521 AND AFTER ..... SECTION 4003
SPECIAL TOOLS 4003-4
FUSES AND RELAY IDENTIFICATION 4003-5
Cab Fuses/Relay Location 4003-5
Engine Compartment Fuse/Relay Identification (Power Distribution Box) 4003-5
Fuse Identification 4003-6
Relays 4003-7
INSTRUMENTATION AND CONTROLS 4003-8
CONNECTOR AND COMPONENT LOCATIONS 4003-12
Cab Exterior 4003-12
Cab Interior 4003-15
Engine/Engine Compartment 4003-20
Transmission 4003-27
Hitch System 4003-31
ELECTRICAL CONNECTORS 4003-33
ELECTRICAL SYSTEMS SCHEMATICS AND DIAGNOSTICS 4003-141
Power Distribution System Circuit Operation 4003-141
Power Distribution Circuit Troubleshooting 4003-141
Power Distribution Schematic 4003-141
POWER DISTRIBUTION SYMPTOM CHART 4003-142
Diagnostic Tests 4003-143
AUDIO SYSTEM 4003-147
Audio System Circuit Operation 4003-147
Audio System Circuit Troubleshooting 4003-147
Audio System Symptom Chart 4003-147
Audio System Diagnostic Tests 4003-149
CHARGING SYSTEM 4003-153
Charging System Circuit Operation 4003-153
Charging System Circuit Troubleshooting 4003-153
Charging System Symptom Chart 4003-154
Charging System Diagnostic Tests 4003-155
EXTERIOR LIGHTING SYSTEM 4003-159
Exterior Lighting System Circuit Operation 4003-159
Exterior Lighting System Circuit Troubleshooting 4003-159
Exterior Lighting System Symptom Chart 4003-160
Exterior Lighting System Diagnostic Tests 4003-160
INSTRUMENTATION AND WARNING SYSTEM 4003-165
Instrumentation and Warning System Circuit Troubleshooting 4003-165
Instrumentation and Warning System Symptom Chart 4003-165
Instrumentation and Warning System Diagnostic Tests 4003-166

INTERIOR LIGHTING AND HORN SYSTEM 4003-169
Interior Lighting and Horn System Circuit Operation 4003-169
Interior Lighting and Horn System Circuit Troubleshooting 4003-169
Interior Lighting and Horn System Symptom Chart 4003-170
Interior Lighting and Horn System Diagnostic Tests 4003-170
POWER MIRROR SYSTEM 4003-174
Power Mirror Circuit Operation 4003-174
Power Mirror Circuit Troubleshooting 4003-174
Power Mirror System Symptom Chart 4003-175
Power Mirror System Diagnostic Tests 4003-177
POWER SEAT SYSTEM 4003-186
Power Seat System Circuit Operation 4003-186
Power Seat System Circuit Troubleshooting 4003-186
Power Seat System Symptom Chart 4003-187
Power Seat System Diagnostic Tests 4003-188
STARTING SYSTEM 4003-192
Starting System Circuit Operation 4003-192
Starter Motor Circuit Troubleshooting 4003-192
Starting System Symptom Chart 4003-192
Starting System Diagnostic Tests 4003-194
WIPER/WASHER SYSTEM 4003-199
Wiper/Washer System Circuit Operation 4003-199
Wiper/Washer System Circuit Troubleshooting 4003-199
Wiper/Washer System Symptom Chart 4003-200
Wiper/Washer System Diagnostic Tests 4003-201

BOOK 2 - Power Train - 87678525

POWERSHIFT TRANSMISSION SYSTEM - HOW IT WORKS AND TROUBLESHOOTING ..... SECTION 6000
TRANSMISSION SYSTEM INTRODUCTION 6000-3
TRANSMISSION SYSTEM CONTROLS 6000-5
TRANSMISSION SYSTEM COMPONENTS 6000-6
TRANSMISSION LUBE AND DISTRIBUTION TUBES 6000-8
POWERSHIFT TRANSMISSION CLUTCH LAYOUT 6000-10
POWERSHIFT VALVE CLUTCH ENGAGEMENTS 6000-11
POWER FLOW (REVERSE SPEEDS) 6000-30
POWER FLOW (REVERSE SPEEDS) 6000-32
POWER FLOW (FORWARD CREEPER DRIVE SPEEDS) 6000-34
POWER FLOW (REVERSE CREEPER DRIVE SPEEDS) 6000-40
INCHING VALVE OPERATION 6000-42
INSTRUMENTATION CLUSTER - TRANSMISSION LEAKAGE CHECK 6000-46
MASTER CLUTCH PRESSURE CHECK 6000-49

TRANSMISSION INPUT SHAFT AND DRIVE PLATE ..... SECTION 6001
SPECIAL TORQUES 6001-3
TRANSMISSION INPUT SHAFT AND DRIVE PLATE REMOVAL 6001-4
TRANSMISSION INPUT SHAFT AND DRIVE PLATE INSTALLATION 6001-8

INPUT DROP BOX ..... SECTION 6002
SPECIAL TOOLS 6002-3
SPECIAL TORQUES 6002-3
INPUT DROP BOX 6002-4
DISASSEMBLY 6002-6

ENGINE FRAME AND DROP BOX SPLIT ..... SECTION 6003
SPECIAL TORQUES 6003-3
SPECIAL TOOLS 6003-3
ENGINE FRAME AND DROP BOX SPLIT 6003-4
REMOVAL 6003-4
INSTALLATION 6003-6

SPEED TO RANGE TRANSMISSION SPLIT ..... SECTION 6005
SPECIAL TOOLS 6005-3
SPECIAL TORQUES 6005-3
SPEED TO RANGE TRANSMISSION SPLIT 6005-4
REMOVAL 6005-4
INSTALLATION 6005-7

SPEED TRANSMISSION ..... SECTION 6006
PICTORIAL INDEX - SPEED TRANSMISSION 6006-3
SPECIFICATIONS 6006-4
SPECIAL TORQUES 6006-4
TROUBLESHOOTING AFTER SPEED TRANSMISSION REPAIR 6006-4
SPECIAL TOOLS 6006-5
SPEED TRANSMISSION WITH CREEP OPTION 6006-6
ASSEMBLING THE COUNTERSHAFT WITH CREEPER SPEED CLUTCH 6006-14
TRANSMISSION ASSEMBLY WITH CREEP OPTION 6006-78
TRANSMISSION ASSEMBLY WITHOUT CREEP OPTION 6006-80

RANGE TRANSMISSION TO REAR FRAME SPLIT ..... SECTION 6007
SPECIAL TOOLS 6007-3
SPECIAL TORQUES 6007-3
RANGE TRANSMISSION TO REAR FRAME SPLIT 6007-4
DISASSEMBLY 6007-4
ASSEMBLY 6007-7

RANGE TRANSMISSION ..... SECTION 6008
SPECIFICATIONS 6008-3
TROUBLESHOOTING AFTER RANGE TRANSMISSION REPAIR 6008-3
SPECIAL TORQUES 6008-3
SPECIAL TOOLS 6008-4
RANGE TRANSMISSION 6008-5
Removing the Shaft Master Clutch 6008-5
Removing the Input Shaft, Countershaft and Mechanical Front Drive (MFD) / Park Brake Assembly 6008-7
Disassembly of the Master Clutch 6008-12
Exploded View of the Master Clutch 6008-14
Assembly of the Master Clutch 6008-15
Disassembly of the Range Transmission Input Shaft 6008-16
Exploded View of the Range Transmission Input Shaft 6008-22
Assembly of the Range Transmission Input Shaft 6008-23
Cross-Section of Input Shaft 6008-32
Disassembly of the Range Transmission Countershaft 6008-33
Exploded View of the Range Transmission Countershaft 6008-37
Assembly of the Range Transmission Countershaft 6008-38
Mechanical Front Drive (MFD) - Emergency Brake Disassembly 6008-45
Exploded View of MFD and Emergency Brake 6008-51
Assembly of the MFD / Emergency Brake 6008-52
Exploded View of the Range Transmission Countershaft, Input Shaft, and MFD Input Shaft 6008-66
Installing the Range Transmission Countershaft, Input Shaft,
and MFD Input Shaft into the Range Transmission Housing 6008-67

SETTING THE END PLAY OF THE RANGE TRANSMISSION COUNTERSHAFT AND INPUT SHAFT 6008-73
Installing the Range Input Master Clutch 6008-75

TRANSMISSION CONTROL VALVES AND INCHING VALVE ..... SECTION 6009
SPECIAL TORQUES 6009-3
POWERSHIFT TRANSMISSION CONTROL VALVES 6009-3
TRANSMISSION CONTROL VALVE CONFIGURATION 6009-4
INCHING VALVE 6009-15

REAR FRAME ..... SECTION 6011
(NOTE: Book 2A contains updated information in Section 6011. Use Section 6011 in Book 2A in place of this original section.)

HYDRAULIC PUMP DRIVE ..... SECTION 6012
SPECIAL TORQUES 6012-3
SPECIFICATIONS 6012-3
PUMP DRIVE 6012-3
Removal 6012-3
Disassembly 6012-4
Assembly 6012-7
Installation 6012-12

MECHANICAL FRONT DRIVE (MFD) CONTROL SYSTEM - HOW IT WORKS ..... SECTION 6013
MECHANICAL FRONT DRIVE (MFD) 6013-3
ELECTRONIC MFD CONTROL 6013-5
MFD CONTROL MODES 6013-7
MFD FUNCTIONAL TESTS 6013-8
MFD Valve 6013-9
Solenoid Cartridge Valve 6013-9
TROUBLESHOOTING 6013-10

DIFFERENTIAL LOCK CONTROL SYSTEM - HOW IT WORKS ..... SECTION 6014
ELECTRONIC DIFFERENTIAL LOCK CONTROL 6014-5
DIFFERENTIAL LOCK CONTROL MODES 6014-7
DIFFERENTIAL LOCK CONTROL 6014-8
DIFFERENTIAL LOCK FUNCTIONAL TESTS 6014-9
TROUBLESHOOTING 6014-12
PTO/DIFFERENTIAL LOCK VALVE CIRCUIT 6014-15

BOOK 2A - Power Train (Continued) - 87710918

REAR FRAME ..... SECTION 6011
SPECIFICATIONS 6011-3
SPECIAL TORQUES 6011-3
SPECIAL TOOLS 6011-3
DIFFERENTIAL 6011-4
Removal 6011-4
Disassembly 6011-10
PINION SHAFT 6011-14
Removal and Disassembly 6011-14
Assembly and Installation 6011-16
HEAVY DUTY PINION SHAFT 6011-23
Removal and Disassembly 6011-23
Assembly and Installation 6011-25
DIFFERENTIAL ASSEMBLY 6011-31
DIFFERENTIAL INSTALLATION 6011-36
ADJUSTING THE DIFFERENTIAL PRELOAD 6011-43
ADJUSTING THE RING AND PINION BACKLASH 6011-45
BEVEL PINION AND GEAR TOOTH CONTACT CHECK 6011-46

BOOK 3 - Power Train (Continued), Brakes - 87689443

MFD OUTPUT SHAFT ..... SECTION 6015
SPECIAL TORQUES 6015-3
MFD OUTPUT SHAFT 6015-4

MFD DRIVE SHAFT ..... SECTION 6016
SPECIAL TORQUES 6016-3
MFD DRIVE SHAFT REMOVAL 6016-4
MFD DRIVE SHAFT INSTALLATION 6016-6

LIMITED SLIP MFD DIFFERENTIAL ..... SECTION 6017
SPECIFICATIONS 6017-2
SPECIAL TORQUES 6017-2
SPECIAL TOOLS 6017-2
DIFFERENTIAL CARRIER ASSEMBLY REMOVAL 6017-3
DIFFERENTIAL DISASSEMBLY 6017-4
Pinion Disassembly 6017-8
DIFFERENTIAL ASSEMBLY 6017-11
DIFFERENTIAL CARRIER ASSEMBLY 6017-15
Pinion Position and Assembly 6017-15
Shim Pack Thickness Chart 6017-16
Setting The Pinion Depth 6017-17
Adjusting Bearing Preload 6017-20
DIFFERENTIAL INSTALLATION 6017-22
Checking Backlash 6017-23
Ring Gear and Pinion Tooth Pattern Interpretation 6017-25
Installation of Carrier Assembly to Axle Housing 6017-27

LOCKING MFD DIFFERENTIAL ..... SECTION 6018
SPECIFICATIONS 6018-3
SPECIAL TORQUES 6018-3
SPECIAL TOOLS 6018-3
REMOVAL OF THE FRONT DIFFERENTIAL CARRIER ASSEMBLY 6018-4
REMOVAL OF THE FRONT DIFFERENTIAL FROM THE CARRIER HOUSING 6018-5
DISASSEMBLY OF THE DIFFERENTIAL 6018-7
PINION DISASSEMBLY 6018-9
ASSEMBLY OF THE DIFFERENTIAL 6018-12
DIFFERENTIAL CARRIER ASSEMBLY 6018-16
SETTING THE PINION DEPTH 6018-18
ADJUSTING BEARING PRELOAD 6018-21
DIFFERENTIAL INSTALLATION 6018-23

REAR AXLE AND PLANETARIES ..... SECTION 6019
SPECIAL TOOLS 6019-3
SPECIAL TORQUES 6019-5
SPECIFICATIONS 6019-5
GENERAL INFORMATION 6019-5
REAR AXLE 6019-6
AXLE HOUSING DISASSEMBLY 6019-9
PLANETARY DISASSEMBLY 6019-11
DIFFERENTIAL CARRIER SEAL REPLACEMENT 6019-13
PLANETARY ASSEMBLY - THREE PIN 6019-14
PLANETARY ASSEMBLY - FOUR PIN 6019-15
AXLE HOUSING ASSEMBLY 6019-18
HOW TO DETERMINE RAM PRESSURE 6019-23
AXLE INSTALLATION 6019-26
AXLE SEAL WEAR SLEEVE INSTALLATION (4-Inch Axle Only) 6019-30

POWER TAKE OFF CONTROL SYSTEM - HOW IT WORKS ..... SECTION 6020
POWER TAKE OFF 6020-3
ELECTRONIC PTO CONTROL 6020-4
PTO SYSTEM CONTROL 6020-7
PTO CONTROL MODES 6020-8
PTO VALVE OIL SUPPLY 6020-10
PTO/DIFFERENTIAL LOCK VALVE 6020-11
TROUBLESHOOTING 6020-12
PTO CLUTCH ENGAGED 6020-13
TROUBLESHOOTING 6020-14

MFD PLANETARY HUB, STEERING KNUCKLE AND DRIVE SHAFT ..... SECTION 6022
SPECIFICATIONS 6022-3
SPECIAL TORQUES 6022-3
SPECIAL TOOLS 6022-3
PLANETARY HUB DISASSEMBLY 6022-4
STEERING KNUCKLE AND KINGPIN DISASSEMBLY 6022-9
AXLE DRIVE SHAFT DISASSEMBLY 6022-13
AXLE SHAFT ASSEMBLY 6022-14
KINGPIN ASSEMBLY 6022-16
STEERING KNUCKLE ASSEMBLY 6022-20
PLANETARY HUB ASSEMBLY 6022-24
Ten Bolt Axle Only 6022-29
Twelve Bolt Axle Only 6022-33
All Axles 6022-38

SUSPENSION MFD AXLE ..... SECTION 6023
SPECIAL TORQUES 6023-2
SUSPENSION MFD AXLE 6023-3
Disassembly 6023-3
Assembly 6023-13
Position Sensor Adjustment 6023-25

SUSPENSION MFD AXLE SYSTEM - HOW IT WORKS AND TROUBLESHOOTING ..... SECTION 6024
SUSPENDED MFD AXLE OPERATION 6024-3
SUSPENDED MFD AXLE- CALIBRATION MODE 6024-9
ERROR TABLE 6024-11
SUSPENDED MFD AXLE- MANUAL OPERATION MODE (TEST MODE) 6024-13
SUSPENDED MFD AXLE- DEMONSTRATION MODE 6024-16

PTO CLUTCH ASSEMBLY SINGLE, REVERSIBLE AND DUAL SPEED ..... SECTION 6025
(NOTE: Book 3A contains updated information in Section 6025. Use Section 6025 in Book 3A in place of this original section.)

BRAKE VALVE ..... SECTION 7001
SPECIAL TORQUES 7001-2
BRAKE VALVE 7001-3
Removal 7001-3
Disassembly 7001-4
Assembly 7001-6
Installation 7001-8

BRAKE CYLINDERS ..... SECTION 7002
SPECIAL TORQUES 7002-3
SPECIFICATIONS 7002-3
BRAKE CYLINDERS 7002-3
Disassembly 7002-3
Assembly 7002-5

BOOK 3A - Power Train (Continued), Brakes - 87710919

PTO CLUTCH ASSEMBLY SINGLE, REVERSIBLE AND DUAL SPEED ..... SECTION 6025
SPECIAL TOOLS 6025-3
SPECIAL TORQUES 6025-3
PTO CLUTCH ASSEMBLY 6025-4
General 6025-4
PTO CLUTCH SERVICE 6025-4
Removal 6025-4
Disassembly 6025-6
Assembly 6025-16
Exploded View of PTO Clutch 6025-16
Cross Section of PTO Clutch and Output Shaft Assembly 6025-33
SINGLE SPEED REVERSIBLE SHAFT PTO 6025-34
Disassembly 6025-34
Assembly 6025-37
Exploded View of PTO Output Shaft and Driven Gear Assembly 6025-37
SINGLE SPEED REVERSIBLE SHAFT PTO DRIVEN GEAR 6025-41
Removal 6025-41
Assembly 6025-43
Reversible PTO Output Shaft Bearing Adjustment 6025-45
SINGLE SPEED REVERSIBLE SHAFT PTO 6025-47
Cross Section of PTO Output Shaft Assembly 6025-47

BOOK 4 - Hydraulics, Chassis - 87710920

HYDRAULIC SCHEMATIC - NORTH AMERICAN 87518874

HOW TO READ SYMBOLS IN A HYDRAULIC SCHEMATIC ..... SECTION 8000
SIMPLE SCHEMATIC 8000-13
COMMON SYMBOLS 8000-15

HYDRAULIC SYSTEM - HOW IT WORKS AND TROUBLESHOOTING ..... SECTION 8001
GENERAL INTRODUCTION 8001-3
REAR CHARGE/LUBE PUMP PRESSURE TEST 8001-19
REAR CHARGE/LUBE PUMP FLOW TEST 8001-21
REGULATED SYSTEM PRESSURE TEST AND ADJUSTMENT PROCEDURE 8001-22
FRONT/REGULATED SYSTEM PUMP FLOW TEST 8001-26
STEERING RELIEF PRESSURE TEST AND ADJUSTMENT PROCEDURE 8001-28
STEERING SYSTEM PROBLEMS 8001-30
PRIORITY AND REGULATOR VALVE 8001-32
PFC AXIAL PISTON PUMP 8001-35
PFC PUMP HIGH PRESSURE STANDBY CHECK AND ADJUSTMENT PROCEDURE 8001-45
PFC PISTON PUMP FLOW CHECK AT REMOTE COUPLERS 8001-46
PFC PISTON PUMP FLOW TEST 8001-48
TWINFLOW PFC PISTON PUMP FLOW TEST 8001-50
PFC PISTON PUMP FLOW COMPENSATOR SETTING 8001-52
PUMP COMPENSATOR VALVE INSPECTION 8001-54
POWER BEYOND SYSTEM 8001-55
FLOW CHECK AT POWER BEYOND COUPLERS 8001-57
PFC PUMP OPERATIONAL PROBLEMS 8001-59

PTO AND DIFFERENTIAL LOCK VALVE....SECTION 8002
SPECIAL TORQUES 8002-2
SPECIFICATIONS 8002-2
PTO AND DIFFERENTIAL LOCK VALVE 8002-3

REMOTE VALVE AND COUPLER SERVICE....SECTION 8003
SPECIAL TORQUES 8003-2
REMOTE VALVE AND COUPLER SERVICE 8003-3
REMOTE VALVE REMOVAL AND SERVICE 8003-5
REMOTE COUPLERS 8003-13

REMOTE HYDRAULIC SYSTEM - HOW IT WORKS AND TROUBLESHOOTING....SECTION 8004
REMOTE HYDRAULIC SYSTEM INTRODUCTION 8004-3
REMOTE VALVE SYSTEM COMPONENTS 8004-5
REMOTE VALVE SYSTEM CONTROLS 8004-11
REMOTE VALVE OPERATION 8004-15
REMOTE VALVE PROBLEMS AND WHERE TO LOOK 8004-24
REMOTE VALVE PROPORTIONAL CURRENT CONTROL (PCC) SOLENOID OPERATION 8004-26
PFC PISTON PUMP FLOW CHECK AT REMOTE COUPLERS 8004-27
REMOTE VALVE SYSTEM TESTING 8004-29
PFC VALVE HIGH PRESSURE TEST 8004-30
PFC HIGH PRESSURE STANDBY CHECK AND ADJUSTMENT PROCEDURE 8004-31
STANDARD PUMP COMPENSATOR VALVE INSPECTION 8004-32
REMOTE VALVE SIGNAL CHECK AND HITCH SIGNAL CHECK 8004-33
REMOTE VALVE COUPLER TEST 8004-34
LOAD CHECK INSPECTION 8004-35
OPERATIONAL PROBLEMS 8004-36

PRIORITY AND REGULATOR VALVE....SECTION 8005
SPECIAL TORQUES 8005-3
PRIORITY VALVE AND REGULATOR 8005-4
Removal 8005-4
Disassembly 8005-6
Assembly 8005-9
Installation 8005-12
CROSS SECTION OF PRIORITY AND REGULATOR VALVE 8005-14

CHARGE PUMP....SECTION 8006
CHARGE PUMP 8006-3
Removal 8006-3
Installation 8006-4

PFC PISTON PUMP AND HYDRAULIC FILTER....SECTION 8007
SPECIAL TORQUES 8007-3
PFC PISTON PUMP 8007-3
Removal 8007-3
Installation 8007-5

HITCH SYSTEM - HOW IT WORKS....SECTION 8008
THREE POINT HITCH 8008-3
ELECTRONIC HITCH CONTROL 8008-4
HITCH CONTROL VALVE 8008-14
General 8008-14
Raise and Lower Solenoids 8008-14
Raise and Lower Pilot Spools 8008-14
Raise Spool 8008-14
Lower Poppet 8008-14

Click on the image link below for the full version of the service manual

