SERVICE MANUAL

CRAWLER

850E

855E

8-17012

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

SERVICE MANUAL

CRAWLER

850E

855E

8-17012

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

SERVICE MANUAL

CRAWLER

850E

855E

8-17012

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

SERVICE MANUAL

CRAWLER

850E

855E

8-17012

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

850E/855E Crawler
Service Manual
8-17012
Table of Contents

Description	Section No.	Form No.
General	**Tab 1**	
Section Index - General		8-19180
Standard Torque Specifications	1001	8-71601
Fluids and Lubricants	1002	8-18970
Loctite Product Chart		8-98900
Engine	**Tab 2**	
Section Index - Engine		7-43920
Engine Stall Tests	2000	8-19190
Removal and Installation and Radiator Removal and Installation	2001	8-19200
Detailed Engine Specifications	2401	8-26063
Cylinder Head and Valve Train	2415	8-26073
Cylinder Block	2425	8-28084
Lubrication System	2445	8-26093
Cooling System	2455	8-26103
Turbocharger	2465	8-26110
Turbocharger Failure Analysis	2565	9-78235
Fuel System	**Tab 3**	
Section Index - Fuel System		8-19210
Fuel System and Filters	3410	8-26131
Fuel Injection Pump - CAV	3411	8-97711
Fuel Injection Pump - Bosch	3412	8-26143
Fuel Injectors	3413	8-26152
Electrical	**Tab 4**	
Section Index - Electrical		8-19220
Electrical Specifications, Troubleshooting and Schematic	4001	8-19230
Starter and Starter Solenoid	4002	8-73830
Batteries	4003	8-11361
Instrument panel and Gauges	4004	8-19020
Alternator	4009	8-16570
Track	**Tab 5**	
Section Index - Track		8-14520
Undercarriage Fundamentals	5001	8-99830
Inspection of Track System Components	5501	8-19160
Case Lubricated Track	5504	8-14531
Sealed Track and Track Frame	5506	8-14541
Idler, Track Adjuster and Recoil Housing	5508	8-14550
Sprocket	5509	8-19240
Carrier Roller	5510	8-14570
Track Roller	5511	8-14580

850E/855E Crawler
Service Manual

Table of Contents

Description	Section No.	Form No.
Power Train	**Tab 6**	
Section Index - Power Train		8-14590
Specifications, Schematic and Troubleshooting	6002	8-19030
Torque Converter and Torque Converter Housing	6006	8-14610
Transmission Control Valve	6007	8-19040
Modulator Valve	6008	8-19050
Transmission	6016	8-19061
Final Drive	6017	8-14641
Brakes	**Tab 7**	
Section Index - Brakes		8-19070
Removal and Installation of Brake Valve and Removing Air from the Brake System	7001	8-19080
Brake Valve	7002	8-19090
Brakes	7003	8-19101
Hydraulics	**Tab 8**	
Section Index - Hydraulics		7-43890
Removal and Installation of Control Valves and Pump	8001	7-44640
Specifications, Troubleshooting and Schematics	8002	8-19250
Cleaning the Hydraulic System	8003	8-14710
Equipment Pump	8005	8-14720
Loader Control Valve	8006	8-19260
Dozer Control Valve	8007	8-19300
Cylinders	8008	8-19271
Backhoe Control Valve	8009	7-43860
Stabilizer Control Valve	8010	7-43870
Mounted Equipment	**Tab 9**	
Section Index - Mounted Equipment		8-19280
Pedals and Levers	9000	8-19290
Air Conditioning Troubleshooting	9001	8-18910
Discharging and Charging Air Conditioning System	9002	8-19310
Air Conditioning Compressor and Clutch	9003	8-19320
Loader	9004	8-19330
Dozer Blade	9005	8-19340
Backhoe	9006	7-34880
Ripper	9031	8-14780
ROPS Cab and Canopy	9061	8-19350
Suspension Seat	9063	7-43910

Rac 8-19172

Printed in U.S.A.
November, 1992

Section 1001

STANDARD TORQUE SPECIFICATIONS

TABLE OF CONTENTS

TORQUE SPECIFICATIONS - DECIMAL HARDWARE 2

TORQUE SPECIFICATIONS - METRIC HARDWARE 3

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 4

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 5

TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphities, Molydisulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs



Size	Pound-Inches	Newton metres
1/4 inch	108 to 132	12 to 15
5/16 inch	204 to 252	23 to 28
3/8 inch	420 to 504	48 to 57
Size	Pound-Feet	Newton metres
7/16 inch	54 to 64	73 to 87
1/2 inch	80 to 96	109 to 130
9/16 inch	110 to 132	149 to 179
5/8 inch	150 to 180	203 to 244
3/4 inch	270 to 324	366 to 439
7/8 inch	400 to 480	542 to 651
1.0 inch	580 to 696	787 to 944
1-1/8 inch	800 to 880	1085 to 1193
1-1/4 inch	1120 to 1240	1519 to 1681
1-3/8 inch	1460 to 1680	1980 to 2278
1-1/2 inch	1940 to 2200	2631 to 2983

Grade 8 Bolts, Nuts, and Studs



Size	Pound-Inches	Newton metres
1/4 inch	144 to 180	16 to 20
5/16 inch	288 to 348	33 to 39
3/8 inch	540 to 648	61 to 73
Size	Pound-Feet	Newton metres
7/16 inch	70 to 84	95 to 114
1/2 inch	110 to 132	149 to 179
9/16 inch	160 to 192	217 to 260
5/8 inch	220 to 264	298 to 358
3/4 inch	380 to 456	515 to 618
7/8 inch	600 to 720	814 to 976
1.0 inch	900 to 1080	1220 to 1465
1-1/8 inch	1280 to 1440	1736 to 1953
1-1/4 inch	1820 to 2000	2468 to 2712
1-3/8 inch	2380 to 2720	3227 to 3688
1-1/2 inch	3160 to 3560	4285 to 4827

NOTE: *Use thick nuts with Grade 8 bolts.*

Retyped November,

Rac 8-71601 Issued 11-91 Printed in U.S.A

TORQUE SPECIFICATIONS - METRIC HARDWARE

Use the following torques when specifications are not given.

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or Molydisulfide grease or oil is used.

Grade 8.8 Bolts, Nuts, and Studs



Size	Pound-Inches	Newton metres
M4	24 to 36	3 to 4
M5	60 to 72	7 to 8
M6	96 to 108	11 to 12
M8	228 to 276	26 to 31
M10	456 to 540	52 to 61
Size	**Pound-Feet**	**Newton metres**
M12	66 to 79	90 to 107
M14	106 to 127	144 to 172
M16	160 to 200	217 to 271
M20	320 to 380	434 to 515
M24	500 to 600	675 to 815
M30	920 to 1100	1250 to 1500
M36	1600 to 1950	2175 to 2600

Grade 10.9 Bolts, Nuts, and Studs



Size	Pound-Inches	Newton metres
M4	36 to 48	4 to 5
M5	84 to 96	9 to 11
M6	132 to 156	15 to 18
M8	324 to 384	37 to 43
Size	**Pound-Feet**	**Newton metres**
M10	54 to 64	73 to 87
M12	93 to 112	125 to 150
M14	149 to 179	200 to 245
M16	230 to 280	310 to 380
M20	450 to 540	610 to 730
M24	780 to 940	1050 to 1275
M30	1470 to 1770	2000 to 2400
M36	2580 to 3090	3500 to 4200

Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound-Inches	Newton metres
37 Degree Flare Fitting			
1/4 inch 6.4 mm	7/16-20	72 to 144	8 to 16
5/16 inch 7.9 mm	1/2-20	96 to 192	11 to 22
3/8 inch 9.5 mm	9/16-18	120 to 300	14 to 34
1/2 inch 12.7 mm	3/4-16	180 to 504	20 to 57
5/8 inch 15.9 mm	7/8-14	300 to 696	34 to 79
Tube OD Hose ID	Thread Size	Pound-Inches	Newton metres
3/4 inch 19.0 mm	1-1/16-12	40 to 80	54 to 108
7/8 inch 22.2 mm	1-3/16-12	60 to 100	81 to 135
1.0 inch 25.4 mm	1-5/16-12	75 to 117	102 to 158
1-1/4 inch 31.8 mm	1-5/8-12	125 to 165	169 to 223
1-1/2 inch 38.1 mm	1-7/8-12	210 to 250	285 to 338

Tube OD Hose ID	Thread Size	Pound-Inches	Newton metres
Straight Threads with O-ring			
1/4 inch 6.4 mm	7/16-20	144 to 228	16 to 26
5/16 inch 7.9 mm	1/2-20	192 to 300	22 to 34
3/8 inch 9.5 mm	9/16-18	300 to 480	34 to 54
1/2 inch 12.7 mm	3/4-16	540 to 804	57 to 91
Tube OD Hose ID	Thread Size	Pound-Inches	Newton metres
5/8 inch 15.9 mm	7/8-14	58 to 92	79 to 124
3/4 inch 19.0 mm	1-1/16-12	80 to 128	108 to 174
7/8 inch 22.2 mm	1-3/16-12	100 to 160	136 to 216
1.0 inch 25.4 mm	1-5/16-12	117 to 187	159 to 253
1-1/4 inch 31.8 mm	1-5/8-12	165 to 264	224 to 357
1-1/2 inch 38.1 mm	1-7/8-12	250 to 400	339 to 542

Split Flange Mounting Bolts		
Size	Pound-Inches	Newton metres
5/16-18	180 to 240	20 to 27
3/8-16	240 to 300	27 to 34
7/16-14	420 to 540	47 to 61
Size	Pound-Feet	Newton metres
1/2-13	55 to 65	74 to 88
5/8-11	140 to 150	190 to 203

Section

2001

ENGINE REMOVAL AND INSTALLATION
RADIATOR REMOVAL AND INSTALLATION

Click on the image link below for the full version of the service manual

