CX80C
Crawler Excavator

SERVICE MANUAL

Part number 48098410
English
May 2017
© 2017 CNH Industrial Italia S.p.A. All Rights Reserved.

CASE
CONSTRUCTION

SERVICE MANUAL

CX80C Crawler Excavators standard version (TIER 3)
CX80C Crawler Excavators standard with blade version (TIER 3)

Contents

INTRODUCTION

Engine..... 10

[10.001] Engine and crankcase 10.1

[10.102] Pan and covers 10.2

[10.106] Valve drive and gears 10.3

[10.101] Cylinder heads 10.4

[10.105] Connecting rods and pistons..... 10.5

[10.103] Crankshaft and flywheel..... 10.6

[10.216] Fuel tanks 10.7

[10.218] Fuel injection system..... 10.8

[10.254] Intake and exhaust manifolds and muffler 10.9

[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment..... 10.10

[10.400] Engine cooling system 10.11

[10.414] Fan and drive 10.12

[10.304] Engine lubrication system..... 10.13

Hydraulic systems..... 35

[35.000] Hydraulic systems..... 35.1

[35.300] Reservoir, cooler, and filters..... 35.2

[35.106] Variable displacement pump 35.3

[35.359] Main control valve..... 35.4

[35.357] Pilot system 35.5

[35.525] Auxiliary hydraulic valves and lines 35.6

[35.355] Hydraulic hand control 35.7

[35.356] Hydraulic foot control..... 35.8

[35.352] Hydraulic swing system 35.9

[35.353] Hydraulic travel system 35.10

[35.354] Hydraulic central joint 35.11

[35.736] Boom hydraulic system 35.12
[35.737] Dipper hydraulic system..... 35.13
[35.738] Excavator and backhoe bucket hydraulic system..... 35.14
[35.741] Dozer blade cylinders 35.15
Frames and ballasting 39
[39.140] Ballasts and supports 39.1
Tracks and track suspension 48
[48.130] Track frame and driving wheels..... 48.1
[48.100] Tracks 48.2
[48.134] Track tension units 48.3
[48.138] Track rollers 48.4
Cab climate control 50
[50.100] Heating..... 50.1
[50.200] Air conditioning..... 50.2
Electrical systems 55
[55.000] Electrical system 55.1
[55.100] Harnesses and connectors..... 55.2
[55.015] Engine control system..... 55.3
[55.201] Engine starting system..... 55.4
[55.301] Alternator..... 55.5
[55.302] Battery..... 55.6
[55.640] Electronic modules..... 55.7
[55.512] Cab controls..... 55.8
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system..... 55.9
[55.518] Wiper and washer system..... 55.10
[55.DTC] FAULT CODES..... 55.11
Booms, dippers, and buckets 84
[84.910] Boom..... 84.1

[84.912] Dipper arm 84.2
[84.100] Bucket 84.3
Dozer blade and arm 86
[86.110] Dozer blade 86.1
Platform, cab, bodywork, and decals 90
[90.150] Cab 90.1
[90.156] Cab windshield and windows 90.2
[90.120] Mechanically-adjusted operator seat 90.3
[90.100] Engine hood and panels 90.4

INTRODUCTION

Click on the image link below for the full version of the service manual



Contents

INTRODUCTION

Foreword - Important notice regarding equipment servicing 3
Safety rules 4
Safety rules - General information 5
Safety rules - Personal safety 6
Safety rules - Ecology and the environment 12
Torque - Bolt and nut 13
Torque - Special torque settings 14
Basic instructions - Shop and assembly 18
Hydraulic contamination 20
General specification (*) 21
General specification (*) 25
General specification - Main equipment (*) 29
General specification - Main equipment (*) 35
Weight (*) 41
Weight (*) 43
Dimension (*) 45
Dimension (*) 46
Fluids and lubricants 47
Conversion factors 50
Abbreviation 62
Product identification 65
Product identification - Machine orientation 67

(*) See content for specific models

Foreword - Important notice regarding equipment servicing

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CASE CONSTRUCTION Sales and Service Networks.

Safety rules

Personal safety



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.

Machine safety

NOTICE: *Notice indicates a situation that, if not avoided, could result in machine or property damage.*

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

Information

NOTE: *Note indicates additional information that clarifies steps, procedures, or other information in this manual.*

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

Safety rules - General information

Cleaning

Clean the metal parts with cleaning solution that meets the standard and steam cleaning. (except for bearings)

After cleaning, dry well, and inject oil in all parts.

Also inject oil into the bearings after drying.

Inspection

When disassembling parts, check all the parts.

If there are any worn or damaged parts, replace them.

Inspect carefully to prevent initial breakdowns.

Bearing

Replace any loose bearings.

Air dry bearings before installing them.

Needle bearing

When inserting needle bearings, be very careful not to damage them.

Apply grease to the section where the needle bearing will be inserted.

Gear

Check that there is no wear and no damage.

Oil seal, O-ring, gasket

Always install new oil seals, O-rings, and gaskets.

Apply grease to sections where oil seals and O-rings will be inserted.

Shaft

Check that there is no wear and no damage.

Check the bearings and check for damaged oil seals on the shaft.

Service parts

Install CASE CONSTRUCTION genuine service parts.

When placing an order, check the parts catalog. It contains the CASE CONSTRUCTION genuine part numbers.

Any breakdowns arising from the installation of non-genuine parts are not covered by the warranty.

Lubricants (fuel, hydraulic oil)

Use the oil from the specified company or specified in the operator's manual or service Manual.

Any breakdowns arising from any fuel or hydraulic oil other than those specified are not covered by the warranty.

Safety rules - Personal safety

Preliminary warnings to maintenance operation

⚠ WARNING

Avoid injury!
Do not operate the machine while under the influence of alcohol or drugs.
Failure to comply could result in death or serious injury.

W0160A

⚠ WARNING

Avoid injury!
Shut off the engine, remove the key, and make sure all machine motion stops before you service the machine.
Failure to comply could result in death or serious injury.

W1128B

⚠ WARNING

Improper operation or service of this machine can result in an accident.
Assign a supervisor to direct worksite operations. Agree on all safety measures, procedures, and suitable hand signals.
Failure to comply could result in death or serious injury.

W0287A

⚠ CAUTION

Pinch hazard!
Always use suitable tools to align mating parts. DO NOT use your hand or fingers.
Failure to comply could result in minor or moderate injury.

C0044A

NOTICE: *never operate the engine while wearing a headset to listen to music or radio because it will be difficult to hear the alert signals.*

Personal Protective Equipment (PPE)

⚠ WARNING

Avoid injury!
Use Personal Protective Equipment (PPE), including protective goggles, gloves, and safety footwear.
Failure to comply could result in death or serious injury.

W1036A

Lifting operation

⚠ WARNING

Crushing hazard!
The lifting systems must be operated by qualified personnel who are aware of the correct procedures to follow. Make sure all lifting equipment is in good condition, and all hooks are equipped with safety latches.
Failure to comply could result in death or serious injury.

W0256A

⚠ WARNING

Heavy objects!
Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders.
Failure to comply could result in death or serious injury.

W0398A

⚠ WARNING

Improper operation or service of this machine can result in an accident.
Raised equipment or machine movement without an operator can cause serious injury. Always do the following before performing any maintenance:
Park the machine on flat, level ground.
Lower the attachment to the ground.
Shut down the engine and remove the ignition key.
Lock the tracks.
Failure to comply could result in death or serious injury.

W0944D

⚠ WARNING

Tip-over hazard!
Only raise the track as little as necessary.
Failure to comply could result in death or serious injury.

W0276A

Engine

⚠ DANGER

Avoid injury!
Starting in gear can cause death. Start the engine only from the operator's seat with the transmission control(s) in neutral.
Failure to comply will result in death or serious injury.

D0114A

⚠ WARNING

Inhalation/asphyxiation hazard!
Never operate the engine in a closed building or area. Proper ventilation is required under all circumstances.
Failure to comply could result in death or serious injury.

W0303A

⚠ WARNING

Hazard to bystanders!
Make sure the area surrounding the machine is clear of all persons before starting the engine.
Failure to comply could result in death or serious injury.

W0090A

⚠ WARNING

Hot surface possible!
Wait for all components to cool before performing any operation.
Failure to comply could result in death or serious injury.

W0251A

NOTICE: *be sure to secure the engine solidly to prevent injury or damage to parts due to the engine falling during work on the engine.*

NOTICE: *check before starting the engine that any tools or shop rags used during maintenance have been removed from the area.*

Mechanical components

⚠ WARNING

Entanglement hazard!
Always keep hair and clothing away from moving parts. Do not wear loose clothing, jewelry, or other items that could entangle with moving parts and/or levers.
Failure to comply could result in death or serious injury.

W0445A

⚠ WARNING

Flying objects!
Do not use the implement at a higher Power Take-Off (PTO) RPM than recommended. Machine damage due to vibration may occur, resulting in loose parts and flying debris.
Failure to comply could result in death or serious injury.

W0192A

Battery and electrical system

⚠ WARNING

Explosive gas!
Batteries emit explosive hydrogen gas and other fumes while charging. Ventilate the charging area. Keep the battery away from sparks, open flames, and other ignition sources. Never charge a frozen battery.
Failure to comply could result in death or serious injury.

W0005A

⚠ WARNING

Battery acid causes burns. Batteries contain sulfuric acid.
Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately.
Failure to comply could result in death or serious injury.

W0111A

⚠ WARNING

Battery gas can explode!
To prevent an explosion: 1. Always disconnect the negative (-) battery cable first. 2. Always connect the negative (-) battery cable last. 3. Do not short circuit the battery posts with metal objects. 4. Do not weld, grind, or smoke near a battery.
Failure to comply could result in death or serious injury.

W0011A

NOTICE: *never check the remaining battery charge by shorting out the terminals. This will result in a spark and may cause an explosion or fire. Use a hydrometer to check the remaining battery charge.*

NOTICE: *check the electrical harnesses for cracks, abrasions, and damaged or corroded connectors. Always keep the connectors and terminals clean.*

Hydraulic system

⚠ WARNING

Burn hazard!
Before performing any service on the hydraulic system, you must allow it to cool. Hydraulic fluid temperature should not exceed 40 °C (104 °F).
Failure to comply could result in death or serious injury.

W0241A

⚠ WARNING

Pressurized fluid can penetrate the skin and cause severe injuries.
The grease in the cylinder is under high pressure. Never loosen the grease fitting adaptor completely in order to speed up the flow of grease.
Failure to comply could result in death or serious injury.

W0261A

⚠ WARNING

Pressurized system!
Before attempting any service procedure, it is your responsibility to know the number of accumulators on the machine, and the correct procedure for releasing the pressure of each accumulator.
Failure to comply could result in death or serious injury.

W0136A

Fluids

⚠ WARNING

Hazardous chemicals!
Coolant can be toxic. Avoid contact with skin, eyes, and clothing. Antidotes:
EXTERNAL - Rinse thoroughly with water. Remove soiled clothing.
INTERNAL - Rinse the mouth with water. DO NOT induce vomiting. Seek immediate medical attention.
EYES - Flush with water. Seek immediate medical attention.
Failure to comply could result in death or serious injury.

W0282A

⚠ WARNING

Burn hazard!
Hot coolant can spray and scald if you remove the radiator or deaeration tank cap while the system is hot. To remove the cap: allow the system to cool, turn the cap to the first notch, and wait for all pressure to release. Remove the cap only after all pressure has released.
Failure to comply could result in death or serious injury.

W0367A

⚠ WARNING

Escaping fluid!
Hydraulic fluid or diesel fuel leaking under pressure can penetrate the skin and cause infection or other injury. To prevent personal injury: Relieve all pressure before disconnecting fluid lines or performing work on the hydraulic system. Before applying pressure, make sure all connections are tight and all components are in good condition. Never use your hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see your doctor immediately.
Failure to comply could result in death or serious injury.

W0178A

⚠ WARNING

Chemical hazard!
When handling fuel, lubricants, and other service chemicals, follow the manufacturer's instructions. Wear Personal Protective Equipment (PPE) as instructed. Do not smoke or use open flame. Collect fluids in proper containers. Obey all local and environmental regulations when disposing of chemicals.
Failure to comply could result in death or serious injury.

W0371A

⚠ WARNING

Pressurized hydraulic fluid can penetrate the skin and cause severe injuries.
Tighten all of the connections before starting the engine. If hydraulic fluid has penetrated the skin, seek medical assistance immediately.
Failure to comply could result in death or serious injury.

W0117A

⚠ WARNING

Fuel vapors are explosive and flammable.
Do not smoke while handling fuel. Keep fuel away from flames or sparks. Shut off engine and remove key before servicing. Always work in a well-ventilated area. Clean up spilled fuel immediately.
Failure to comply could result in death or serious injury.

W0904A

⚠ WARNING

Fire hazard!
When handling diesel fuel, observe the following precautions:
1. Do not smoke.
2. Never fill the tank when the engine is running.
3. Wipe up spilled fuel immediately.
Failure to comply could result in death or serious injury.

W0099A

⚠ WARNING

Explosion hazard!
If battery electrolyte is frozen, attempting to charge the battery or jump-start the engine can cause the battery to explode. Always keep batteries at full charge to prevent frozen battery electrolyte. Never charge a frozen battery.
Failure to comply could result in death or serious injury.

W0203A

⚠ WARNING

Fire hazard!
Do not add gasoline, alcohol, or blended fuels to diesel fuel, except as recommended in this manual. Fuel combinations may increase fire and explosion hazards.
Failure to comply could result in death or serious injury.

W0401A

⚠ WARNING

Explosion hazard!
Starting fluid (ether) is flammable. Do not store the starting fluid container in the operator's compartment. Remove the container when temperatures are above 5 °C (40 °F). Wear rubber gloves when handling the container. Do not breathe starting fluid (ether) vapors. Store in a cool place.
Failure to comply could result in death or serious injury.

W0472A

⚠ CAUTION

Escaping fluid!
Hydraulic fluid or diesel fuel leaking under pressure can penetrate the skin and cause infection or other injury. To prevent personal injury: Relieve all pressure before disconnecting fluid lines or performing work on the hydraulic system. Before applying pressure, make sure all connections are tight and all components are in good condition. Never use your hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see your doctor immediately.
Failure to comply could result in minor or moderate injury.

C0104A

⚠ CAUTION

Burn hazard!
Do not remove the radiator cap. Check the coolant level in the recovery tank.
Failure to comply could result in minor or moderate injury.

C0113A

NOTICE: *never overfill the fuel tank.*