Maxxum Tractors

Service Manual Don 7-32487

Table of Contents

	SECTION NO	FORM NO
1 GENERAL		
Sectional Index		7-32752
Safety, General Information and Torque Specifications	1001	8-86531
Specifications (For Tractors Prior to PIN JJF1030000)	1002	7-32673
Specifications (For Tractors From PIN JJF1030000)	1002	7-39641
Loctite Product Chart		8-98900
2 ENGINE		
Sectional Index		7-32762
Engine Removal and Installation	2002	7-33140
Engine Specifications 5130, 5140 and 5150	2401	**See Note**
Engine Specifications 5120	2402	**See Note**
Aftercooler 5120	2411	**See Note**
Cylinder Head and Valve Train 5120	2415	**See Note**
Cylinder Head and Valve Train 5130, 5140 and 5150	2415	**See Note**
Cylinder Block 5120	2425	**See Note**
Cylinder Block 5130, 5140 and 5150	2425	**See Note**
Lubrication System 5120	2445	**See Note**
Lubrication System 5130, 5140 and 5150	2445	**See Note**
Balancer 5120	2447	**See Note**
Cooling System 5120	2455	**See Note**
Cooling System 5130, 5140 and 5150	2455	**See Note**
Turbocharger 5120	2465	**See Note**
Turbocharger 5130, 5140 and 5150	2465	**See Note**
Turbocharger Failure Analysis	2565	**See Note**
3 FUEL SYSTEM		
Sectional Index		7-32771
Fuel Tank and Fuel Tank Sender	3005	8-85032
Fuel System and Filters 5120	3410	**See Note**
Fuel System and Filters 5130, 5140 and 5150	3410	**See Note**
CAV Injection Pump	3411	**See Note**
Bosch Fuel Injection Pump and Drive Gear 5130, 5140 and 5150	3412	**See Note**
Fuel Injector 5120	3413	**See Note**
Fuel Injector 5130, 5140 and 5150	3413	**See Note**
Bosch Fuel Injection Pump 5120	3415	**See Note**
Bosch Fuel Injection Pump With Aneroid	3416	**See Note**

*** Schematic Set Sections (For Tractors Prior to PIN JJF1030000)**

*** * Schematic Set Sections (For Tractors From PIN JJF1030000)**

NOTE: Engine Sections For 5120 Tractors, Please Refer to Engine Service Manual 7-70360

NOTE: Engine Sections For 5130/40/50 Tractors, Please Refer to Engine Service Manual 7-70380

CASE UNITED KINGDOM LIMITED

Don 7-32537

Copyright © 1996 Case Corporation

September 1996

4 ELECTRICAL

Sectional Index		7-32780
Electrical Troubleshooting and Schematics	4001*	7-32501
Electrical Troubleshooting and Schematics (For Tractors With PIN JJF1013658, JJF1013661, JJF1013665, JJF1013667, JJF1013669, JJF1013771, JJF1013772, JJF1013773, JJF1013981 and for Tractors from PIN JJF1015046)	4001*	7-37111
Electrical Troubleshooting and Schematics (For Tractors from PIN JJF1030000)	4001**	7-39280
Electrical Troubleshooting and Schematics For Maxxum Plus Tractors (From PIN JJF1057368) and Maxxum Pro Tractors	4002**	7-70430
Starter Motor	4003	7-41780
Battery Testing, Maintenance and Booster Battery Connections	4004	8-85110
Alternator	4008	7-41790

5 STEERING

Sectional Index		7-32790
Steering Hand Pump (DANFOSS)	5001	8-85130
Steering Hand Pump (EATON)	5001	7-38770
MFD Steering Cylinder	5004	8-85151

6 TRANSMISSION

Sectional Index		7-33432
Separating the Tractor - Engine from Speed Transmission (For Tractors Prior to PIN JJF1030000)	6002	7-32590
Separating the Tractor - Engine from Speed Transmission (For Tractors From PIN JJF1030000)	6002	7-69181
Separating the Tractor - Speed Transmission From Range Transmission	6003	7-32580
Torque Limiter	6004	7-30843
Servicing the Synchromesh Transmission	6005	8-85192
Servicing the Powershift Transmission	6006	8-85203
Servicing the Range Transmission	6007	8-85222
Powershift Transmission Troubleshooting	6008*	7-35320
Powershift Troubleshooting and Schematics (For Tractors With PIN JJF1013658, JJF1013661, JJF1013665, JJF1013667, JJF1013669, JJF1013771, JJF1013772, JJF1013773, JJF1013981 and for Tractors from PIN JJF1015046)	6008*	7-37470
Powershift Troubleshooting and Schematics (For Tractors from PIN JJF1030000)	6008**	7-39451
Powershift Valve	6009	8-85450
Creep Transmission	6011	8-85250
Synchronizer Creep Transmission (For Tractors from PIN JJF1030000)	6011	7-39420
Differential and Differential Lock	6012	8-85242
MFD Drive Shaft	6014	8-85290
MFD Output Shaft	6015	7-70110
MFD Clutch	6017	8-85462

*** Schematic Set Sections (For Tractors Prior to PIN JJF1030000)**

*** * Schematic Set Sections (For Tractors From PIN JJF1030000)**

6 TRANSMISSION (Continued)

Rear Axles and Planetaries	6018	8-85320
Hydraulic PTO (Reversible)	6019	8-85301
Hydraulic PTO (Shiftable)	6020	7-32561
MFD Axle	6021	8-85271
PTO Drive Shaft Gear and Hydraulic Pump Drive Gear	6023	7-32871
Park Lock (Switzerland Only)	6024	7-35370

7 BRAKES

Sectional Index		7-32810
Parking Brake	7001	8-85351
Brake Cylinders and Controls	7002	8-85340
Pneumatic Trailer Brake	7003	7-32540
Hydraulic Trailer Brake Priority Valve	7004	7-32881
Hydraulic Trailer Brake Valve	7005	7-32551

8 HYDRAULICS

Sectional Index		7-32820
Hydraulic Troubleshooting and Schematics (For Tractors Prior to PIN JJF1030000)	8001*	7-32512
Hydraulic Troubleshooting and Schematics (For Tractors from PIN JJF1030000)	8001**	7-39600
Hydraulic Pump Assembly	8002	7-37122
Charge/Lubrication Pump	8003	8-85412
Hydraulic Lift Cylinder and Position Sensor	8004	8-85420
Hitch Adjustments	8005	7-31880
Remote Valves	8006	8-85431
Front Hitch	8007	8-85470
Shuttle Valve	8008	8-88721
Hydraulic Housing and Filter	8009	8-85230
Draft Sensing Valve	8010	7-32100
Shuttle/PTO Valve	8011	7-39631

9 CHASSIS

Sectional Index		7-32830
Pedal and Lever Adjustments	9001*	7-32682
Pedal and Lever Adjustments (For Tractors From PIN JJF1030000)	9001**	7-39440
Air Conditioning Troubleshooting (For Tractors Prior to PIN JJF1034500)	9002	8-85501
Air Conditioning Gauges and Testing (For Tractors Prior to PIN JJF1034500)	9003	8-85511
Air Conditioning System Servicing (For Tractors Prior to PIN JJF1034500)	9004	8-85521
Air Conditioning Component Servicing (For Tractors Prior to PIN JJF1034500)	9005	8-86351

*** Schematic Set Sections (For Tractors Prior to PIN JJF1030000)**

*** * Schematic Set Sections (For Tractors From PIN JJF1030000)**

9 CHASSIS (Continued)

Air Conditioning Troubleshooting (For Tractors From PIN JJF1034500 with HFC-134a Refrigerant)	9002	7-69031
Air Conditioning Gauges and Testing (For Tractors From PIN JJF1034500 with HFC-134a Refrigerant)	9003	7-69041
Air Conditioning System Servicing (For Tractors From PIN JJF1034500 with HFC-134a Refrigerant)	9004	7-69050
Air Conditioning Component Servicing (For Tractors From PIN JJF1034500 with HFC-134a Refrigerant)	9005	7-69062
Cab Removal (For Tractors Prior to JJF1030000)	9006	7-33201
Cab Removal (For Tractors From JJF1030000)	9006	7-69191
Cab Servicing	9007	7-32600
Hood and Panels	9008	8-85540
Operators Seat	9009	8-88730
Decal Location	9010	8-88740
Battery Box	9020	8-89060
Platform Removal	9030	7-32300

*** Schematic Set Sections (For Tractors Prior to PIN JJF1030000)**

*** * Schematic Set Sections (For Tractors From PIN JJF1030000)**

Sectional Index

		SECTION NO.
1	GENERAL	
A	Air Conditioning Specifications	1002
C	Capacities	1002
E	Electrical System Specificaions	1002
G	General Information	1001
H	Hydraulic Specifications	1002
S	Safety Warnings	1001
	Steering Specifications	1002
T	Torque Data	
	Hydraulic Fittings Special Torques	1001
	Standard Nut and Bolt Torques	1001
	Transmission Specifications	1002

Don 7-32752

Copyright © 1992 J I Case Company
Printed in England
August 1992

Click on the image link below for the full version of the service manual



Sectional Index

2 ENGINE

		SECTION NO.
P	Pistons	2425
R	Rocker Arms	2415
	Rods	2425
S	Sleeves	2425
T	Thermostat	2455
	Top Dead Centre (How to Locate)	2415
	Turbocharger	2465
	Turbocharger Failure Analysis	2565
V	Valve Guide Replacement	2415
	Valves	
	Intake and Exhaust	2415
	Dye Pattern Analysis	2415
	Valve Seats	2415
	Valve Train	2415
W	Water Pump	2455

Don 7-32762

Copyright © 1992 J I Case Company
Printed in England
August 1992

Sectional Index

2 ENGINE — SECTION NO.

A Aftercooler 2411

B Bearings 2425
Belt Tensioner 2455
Balancer 2447

C Camshaft 2425
Cooling System (Engine)
Cleaning and Maintenance 2455
Crankshaft Pressure Check (Blow By) 2425
Crankshaft 2425
Cylinder Block 2425
Cylinder Head 2415

E Engine Special Toruques 5130/5140 2401
Engine Special Torques 5120 2402
Engine Specifications 5130/40 2401
Engine Specifications 5120 2402
Engine
Removal 2002
Installation 2002
Expansion Plug Replacement
Cylinder Block 2425
Cylinder Head 2415

F Fan Pulley 2455
Flywheel 2425
Fuel Specifications 5130/40 2401
Fuel Specifications 5120 2402

L Lubrication System 2445

O Oil Cooler (Engine Oil) 2445
Oil Filter Housing 2445
Oil Pan 2445
Oil Pressure Relief Valve 2445
Oil Pump 2445
Oil Seals 2425

Copyright © 1992 J I Case Company

Printed in England
August 1992

Sectional Index

	3 FUEL SYSTEM	SECTION NO.
A	Air Removal	3410
F	Fuel Filters	3410
	Fuel Injectors	3413
	Fuel Shutoff Solenoid	3412
	Fuel Specifications	3410
I	Injectors	3413
	Injection Pump	3412
	Injection Pump Drive Gear	3412
	Injection Pump Timing	3412
	Injection Pump - Bosch	3415
L	Lift (Primer) Pump	3412
P	Primer Pump	3412
T	Timing Lock Pin	3412
	Troubleshooting Guide	3412

Don 7-32771

Copyright © 1991 J I Case Company
Printed in U.S.A.
October 1991